









SKU:6090-PIPE-WT5BR

ASSEMBLY INSTRUCTION

			A 2PCS		B 3PCS				
			C 6PCS		D 60PCS				
E 6PCS		F F1: 1.5 " 36PCS F2: 2.4 " 6PCS F3: 6.3 " 3PCS F4: 12 " 24PCS		G 8PCS		H 30PCS			
I 6PCS		J 8PCS		K 16PCS		L 16PCS		N 1PC	
				M 1PCS					

Please unscrew all spare parts before assembling.
If you find the screw thread is rusty, please don't worry,
it will not affect the installation and use.

SKU:6090-PIPE-WT5BR ASSEMBLY INSTRUCTION




Decomposition Diagram

SKU:6090-PIPE-WT5BR


ASSEMBLY INSTRUCTION

STEP 1



This step*3

STEP 2




This step*24


SKU:6090-PIPE-WT5BR

ASSEMBLY INSTRUCTION

STEP 3




STEP 4




SKU:6090-PIPE-WT5BR

ASSEMBLY INSTRUCTION

STEP 5




STEP 6




SKU:6090-PIPE-WT5BR

ASSEMBLY INSTRUCTION

STEP 7






STEP 8



SKU:6090-PIPE-WT5BR

ASSEMBLY INSTRUCTION

STEP 9



SKU:6090-PIPE-WT5BR

ASSEMBLY INSTRUCTION

STEP 10

Use expansion screws to fix it to the wall.

