



FOR REPLACEMENT PARTS OR HELP WITH ASSEMBLY PLEASE CONTACT US

PLEASE ENSURE TO HAVE THE MODEL # FROM THE PACKAGING OR INSTRUCTION BOOKLET

TO RETURN THE PRODUCT: PLEASE CONTACT THE RETAILER WHERE THE ITEM WAS PURCHASED FROM

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.

CARE and MAINTENANCE


To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth. Dust with soft dry cloth.


Do not use ammonia-based cleaning products, as they will damage the finish. Do not leave liquids or damp cloths on this furniture.


To avoid dulling of the finish, do not place furniture in direct sunlight.


Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.


PRE-ASSEMBLY INFORMATION













ASSEMBLY




- 1. Insert 4 Dowels (5) into pre-drilled holes on the Back (E).
- 2. Use rubber mallet to tap Dowels(5) into bottom of holes securely. 1/2 length of Dowels should be exposed.
- 3. Align Dowels (5) with pre-drilled holes of Sides (B).
- 4. Attach Top Shelf (C) and Back (E) to Sides (B) using Allen Key Screws (1) through pre-drilled holes.

ASSEMBLY

STEP 6



ASSEMBLY



- 1. Insert 2 Dowels (5) into pre-drilled holes on each Side (B).
- 2. Use rubber mallet to tap Dowels (5) into bottom of holes securely. 1/2 length of Dowels should be exposed.
- 3. Attach 4 Cam Lock Pins (2) to Top (A).
- 4. Align Cam Lock Pins with pre-drilled holes and attach Sides B.
- 5. Align pre-drilled holes on bottom corners of Top (A) with Dowels (5) in Sides (B).
- 6. Insert 2 Cam Lock (2) into pre-drilled holes on each Side (B).
- 7. Use flathead screwdriver secure Cam Lock.

<section-header>

- 1. Insert assembled drawer into slots on assembled table.
- 2. Drawer can be inserted into table's opening.

WARRANTY

Thank you for purchasing our product. These products have been made to demanding, high-qualitystandards and are guaranteed for domestic use against manufacturingfaults for a period of 12 months from the date of purchase. This warrantydoes not affect your statutory rights.

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.

Question, problems, missing parts?

Before returning your product

please email or call Customer Support

For more information visit us on our website