


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY




DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)



2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES



When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.



Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List



#1 x 1pc
HeadBoard




#2 x 2pcs
Side Rail




#3 x 1pc
FootBoard




#4 x 1pc
Support Rail




#5 x 4pcs
HB/FB Foot



#6 x 28pcs
Slat




#7 x 2pcs Ø1/4"
Support Leg
250X25X25mm




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Hardware List



#A x 8pcs
Bolt 5/16" X 1"



#B x 6pcs
Bolt 5/16" X 1-1/2"



#C x 8pcs
Bolt 5/16" X 2-3/4"




#D x 22pcs
Flat Washer



#E x 22pcs
Lock Washer



#F x 14pcs
Center Connector



#G x 28pcs
End Cap



#H x 1pc
Allen Wrench



#I x 1pc
Cable A



#J x 1pc
Cable B




#K x 1pc
Power line




Prepare 8 bolts assembly by inserting lock washer (#E), then flat washer (#D) onto bolts (#C). Align HB/FB foot (#4) to the bottom holes of the headboard (#1) and foot board (#2). Secure with bolts (#C).

#C x 8pcs
#D x 8pcs
#E x 8pcs



Prepare 8 bolts assembly by inserting lock washer (#E), then flat washer (#D) onto bolts (#A). Screw bolts (#A) into the holes of the headboard (#1) and footboard (#2) half way in, then hook the side rails (#2) onto bolts (#A) of the headboard (#1) and footboard (#2). Fully tighten bolts (#A).


#A x 8pcs
#D x 8pcs
#E x 8pcs






Prepare 2 bolts assembly by inserting lock washer (#E), then flat washer (#D) onto bolts (#B). Align the support legs (#7) to the holes of the support rails (#4). Secure with bolts (#B).

#B x 2pcs
#D x 2pcs
#E x 2pcs



#B x 4pcs
#D x 4pcs
#E x 4pcs




Prepare 4 bolts assembly by inserting lock washer (#E), then flat washer (#D) onto bolts (#B). Align support rails (#4) to the holes of the headboard (#1) and footboard (#2). Secure with bolts (#B).





Attach slats (#6) with connector caps (#6) and end caps (#G) as shown in the picture, then attach the slats altogether to the holes of the support rails and side rails.

#F x 14pcs
#G x 28pcs



Plug into device

Plug into outlet