

Household simple dirty clothes basket (2 floor)

Product Accessories



- ① Shelf base x1

② Dirty clothes basket x1

③ Storage Basket x1

④ Top shelf panel x1
- ⑤ No card pick support bar x2

⑥ Card support bar x2

⑦ Connect bar x1

⑧ Bottom direction wheel x4



Installation Steps



1. Install the bottom ⑧ universal wheels on ① Bottom of shelf base



2. Installation of ⑤ card-free support rods on ① shelf base



3. Install the ⑦ connection bar on the ⑤ card-free bar



4. Place ② dirty clothes baskets at the base of ① shelf



5. Install ⑥ Card Support Bar on ⑦ Connection Beam



6. Install the ④ top shelf panel on the ⑦ connection bar and insert the ③ receiving basket cards into the card pick holders with the support bar

Household simple dirty clothes basket (3 floor)

Product Accessories



- ① Shelf base x1

② Dirty clothes basket x1

③ Storage Basket x2

④ Top shelf panel x1
- ⑤ No card pick support bar x2

⑥ Card support bar x4

⑦ Connect bar x2

⑧ Bottom direction wheel x4



Installation Steps



1. Install the bottom ⑧ universal wheels on ① Bottom of shelf base



2. Installation of ⑤ card-free support rods on ① shelf base



3. Install the ⑦ connection bar on the ⑤ card-free bar



4. Place ② dirty clothes baskets at the base of ① shelf



5. Install with ② and ③ steps respectively, and then put 3 receiving basket cards into ③ card holders with support rods



6. Install ⑥ Card Support Bar on ⑦ Connection Beam



7. Install the ④ top shelf panel on the ⑦ connection bar