




ITEM NO. SBHM0622

Scan for manual,
video & advice.



If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :


This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
150 LBS



Installation:
75 minutes.



Two Person



Before You Start

Please follow the steps below:



Unbox the package and check if all parts and accessories are complete.



If you find something missing, stop assembly and contact your supplier immediately.



Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.



NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty



We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



Are you having difficulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**




For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance


- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.

Exploded Diagram




Parts List

A x1




Top panel

B x1




Bottom panel

C x1




Front rail

D x1




Left side panel

E x1




Middle left vertical panel

F x1




Middle right vertical panel

G x1




Right side panel

H x1




Back Panel

I x2



Adjustable Shelf

J x1




Adjustable Shelf

K x2



Drawer panel

L x1



Drawer panel

M x3



Left panel of the drawer

N x3




Right panel of the drawer

O x2




Drawer back panel

P x1




Drawer back panel

Q x2




Drawer bottom panel

R x1




Drawer bottom panel

S x1



Door panel


T x1



Door panel


Parts List

U x1



Door panel

V x1



Door panel

W x4



Foot


X x1



Center foot


Hardware List

1 x1



allen key

2 x1



Magnet

3 x28+3



Flat head screw
Ø3*14mm

4 x12+1



shelf pin

5 x8




Knob

6 x8



Flat head screw
Ø4*19mm

7 x24+2




Flat head screw
Ø8*25mm

8 x4




Hinge

9 x4




Hinge

10 x52+5



Flat head screw
Ø3.5*14mm

11 x4



Anti-tip component

12 x4



Expansion pipe

13 x4




Flat head screw
Ø3.5*35mm

14 x2



Hardware pack

15 x1




screwdriver

Assembly Instructions


Step 1


Attach leg (W/X) to bottom panel (B) , tight it with hand



Step 2


Attach Magnet (2) to front rail (C) with screw (3), tight it with screwdriver (15).

2		x 1	Door stopper
3		x 2	Ø3*14mm
15		x 1	screwdriver



Step 3


Slide front rail (C) to middle left vertical panel (E) and middle right vertical panel (F).



Step 4

Attach left side panel (D) and right side panel (G) to preassembly unit at step (3), and tight it with Allen wrench (1).


1	 x 1	M4
---	---	----



Step 5

Connect bottom panel (B) to preassemble unit at step (4), and tight it with Allen wrench (1).


1	 x 1	M4
---	---	----



Step 6

Connect top panel (A) to preassemble unit at step(5), and tight it with Allen wrench (1).


1	 x 1	M4
---	---	----



Step 7

Attach back panel (H) to preassembly unit at step(6) with screw (3),tight screw with screwdriver (15).


3		x 26	Ø3*14mm
15		x 1	screwdriver



Step 8

Insert shelf holder (4) to preassembly unit at step(7), and attach adjustable shelf (I/J) to it.

4		x 12	shelf pin
---	---	------	-----------




Step 9


Connect part (M&N) to part (K) using screw (7) and tighten it with screwdriver (15). Slide in the part (Q) into the groove in part (M&N).make sure they are also in groove in part (K).

7	 x 8	Ø8*25mm
15	 x 1	screwdriver


Step ① x2



Step ② x2



Step ③ x2




Step 10


1. Connect part (M&N) to part (O) using screw(7) and tighten it with screwdriver (15).
2. Attach knob (5) to drawer front left (K) with bolt(6), Tight bolt with screwdriver (15).

5		x 2	Konb
6		x 2	Ø4*19mm
7		x 8	Ø8*25mm
15		x 1	screwdriver

Step ① x2



Step ② x2




Step 11


Connect part (M&N) to part (L) using screw(7) and tighten it with screwdriver(15). Slide in the part (R) into the groove in part (M&N). make sure they are also in groove in part (L).

7	 x 4	Ø8*25mm
15	 x 1	screwdriver


Step ①



Step ②




Step ③



Step 12

1. Connect part (M&N) to part (P) using screw (8) and tighten it with screwdriver (15).
2. Attach knob (5) to drawer front (L) with bolt (6), Tight bolt with screwdriver (15).



5		x 2	Knob
6		x 2	Ø4*19mm
7		x 4	Ø8*25mm
15		x 1	screwdriver




Step 13



Attention: When installing the drawer, slide the steel ball slide rail of side panel to the most front as picture show.




Schematic diagram of slide rail disassembly



Step 14

1. Connect part (8) to part (S/V) with screw (10), tight screw with screwdriver (15).
2. Connect part (5) to part (S/V) with screw (6), tight screw with screwdriver (15).


5		x 2	Knob
6		x 2	Ø4*19mm
8		x 4	Hinge
10		x 8	Ø3.5*14mm
15		x 1	screwdriver



Step 15

1. Connect part (9) to part (T/U) with screw (10), tight screw with screwdriver (15).
2. Connect part (5) to part (T/U) with screw (6), tight screw with screwdriver (15).


5		x 2	M4
6		x 2	Ø4*19mm
9		x 4	Hinge
10		x 8	Ø3.5*14mm
15		x 1	screwdriver



Step 16

Attach left door (S) and right door (V) to preassemble unit at step(15), with screw (10), tight screw with screwdriver (15).


10	 x 16	Ø3.5*14mm
15	 x 1	screwdriver



Step 17


Attach left door (T) and right door (U) to preassemble unit at step(16) , with screw (10), tight screw with screwdriver (15).

10	 x 16	Ø3.5*14mm
15	 x 1	screwdriver




Step 18


Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm
mounting screw or via cam
adjustment!



Concealed hinges are three-way adjustable:



Vertical via slots in
the mounting plate
or via cam adjustment!




Hinge adjustment method

Step 19

Attach bracket (11) to preassemble unit at step(17), with screw(10), and tight screw with screwdriver (15).



10	 x 4	Ø3.5*14mm
11	 x 2	Anti-tip component
15	 x 1	screwdriver




Step 20

Install Anti-tip device (11) to the wall in this step.


11		x 2	
12		x 4	
13		x 4	Ø3.5*35mm
15		x 1	screwdriver



1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor into the hole with a hammer.



3. Secure the Anti-tip device (14) to the wall with screws (15)

Step 21

WARNING




Children have died from furniture tipover.

To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- For use with televisions weighing 35 lb or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



Let the plastic belt (14) pass through the both part(11) and pull tightly.



WWW.HULALAHOME.COM

Email: customerservice@hulalahome.com

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)