

TV Stand



Assembly Instruction



Trouble shooting:

Missing / Wrong / Broken parts and installation issues

↓

Send email with your question pie ,order NO. and screenshot of order details

↓

Respond within 24 hours

↓

Issue resolved

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Thank you for purchasing our products. Please contact us if you have difficulty with assembly or need replacement parts. Our customer service is here to assist you. Please attach your User Name or Order ID so that we can assist you better.

WARNING

Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest drawers or shelves.
6. Never allow children to climb or bang on drawers, doors or shelves.

WARNING







Children have died from furniture tip-over.
To reduce the risk of furniture tip-over:

- ALWAYS anchor the anti-tip device to the wall. Installation is MANDATORY.
- DO NOT set TVs or other heavy objects on top of this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place the heaviest items in the lowest drawers.
















Part List














Please cut if you need, but keep for the future use after assembling








Part List

① ×1		② ×1	
			
③ ×1		④ ×1	⑤ ×1
			
⑥ ×1	⑦ ×1	⑧ ×1	⑨ ×1
			
⑩ ×1	⑪ ×4	⑫ ×1	
			
⑬ ×2	⑭ ×1	⑮ ×1	
			

Part List


⑯ ×2	⑰ ×2	⑱ ×1	⑲ ×1
			
⑳ ×2	㉑ ×2	㉒ ×2	
			
㉓ ×2	㉔ ×1	㉕ ×2	
			

Hardware List


A ×32+3	B ×32+3	C ×42+4	D ×24+2	E ×16+1
			 M4×14	 M3×14
F ×24+2	G ×12+1	H ×2	I ×2	J ×4
 M4×35	 M4×50	 M4×12		 M4×16
K ×2	L ×6	M ×12+1	N ×16+1	O ×2
				
P ×4				
				

Tools required (Please prepare by yourself before installing)

Phillips Screwdriver





Straight Screwdriver



Power Tool NOT Recommended


To ensure proper assembly we have included the following guides:






Insert threads of Locking Bolts completely，and stop once threads are no longer visible.

Do NOT overturn.



Reference this guide when assembling all Cam Locks.


Do NOT overturn.



Notice:"pointer arrow"on cam face the Bolt when inserted the cam.

Step 1


A ×8




Step 2


B ×4

C ×2





Step 3

C ×2	F ×2
	




Step 4

B ×4	C ×4
	




Step 5

A ×5



Step 6

B ×2	C ×1
	




Step 7

F ×4




Step 8

A ×5





Step 9

B ×2	C ×1
	





Step 10

F ×4






Step 11

B ×2	C ×1
	




Step 12



B ×4	C ×1
	




Step 13





Step 14

L ×2	F ×2
	




Step 15


F ×8	C ×8
	




Step 16


A ×8



Step 17






Step 18






Step 19





Step 20

C ×6	G ×12
	




Step 21


A ×6	H ×2	I ×2
		




Step 22




Step 23


B ×6	C ×8	F ×2
		




Step 24





Step 25




Step 26



Step 27


Ⓓ ×8	Ⓙ ×4	Ⓚ ×2	Ⓟ ×4
			




×2


Step 28

D ×16







If the doors have gap problem,you may need:




To adjust the door vertically, loosen the screw as shown and move up and down as needed.



To adjust the gap from the door to the main frame,turn the screw clockwise or anti-clockwise as needed.




To adjust the door horizontally, adjust the screw as shown by turning clockwise or anti-clockwise.





Please fix other screws.


Step 29


E ×16	N ×16
	





Step 30


F ×2	O ×2
	











To reduce the risk of furniture tipping over, you MUST anchor this item to the wall securely by following the steps below:

1) Place this unit in your desired location. Use a pencil to make a small mark on the solid wall through holes on wall bracket (I).
2) Move the unit away and drill holes in the solid wall at the pencil marks.
3) Screw the wall anchor (O) into the wall holes.
4) Place the unit against the wall and fix the screw (F) through the wall bracket (I) into the wall anchor (O).