


360° ULTRASONIC RODENT REPELLER WITH FLASHING LIGHTS

XPT-0011

Review all information before using this product. Save this manual for future reference.



 Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
 Save the packing slip.

PACKAGE CONTENTS	QTY.
Ultrasonic Repeller	1
AC Power Adapter	1

Input Voltage/Current	AC 100-240V
Power Input	DC9V/130-300mA
Power Consumption	<2.7W
Ultrasound Frequency	22-35kHz / 25kHz
Decibel Value	100-125dB
Effective Range	Max. 1930 sq. ft. (180m ²)



CAUTION: RISK OF ELECTRIC SHOCK

TO PREVENT RISK OF ELECTRIC SHOCK OR FIRE, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE. DO NOT OPEN, NO USER SERVICEABLE PARTS.

WARNING:


Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

OPERATION

This product is for indoor use only. Do not use outdoors, in high temperature or humid locations.

Place the unit in proximity of the pest you intend to deter. For mice, install as low as possible to the ground. For spiders, place in proximity of where they make webs.


Do not use this device if you have pet rabbits, pet spiders, or pet rodents (hamsters, guinea pigs, etc), as it may cause them discomfort.



NOTE: This item is intended for continuous use; intermittent use will be less effective. Noticeable results may take several weeks.

When the device is first activated, mice may become more active, this is an indication they are stimulated by the device and actively trying to leave the area.


Select a suitable location with a minimum clearance of 3 feet (1m) surrounding the device.



Plug the power cord into the back of the repeller unit. Then, plug the power cord into a properly grounded AC100-240V outlet.

The device is in standby mode, indicator light is blue/green. The flashing lights are OFF by default.

Select the preferred ultrasonic mode as noted below.



SETTING ULTRASONIC MODE

MODE	INDICATOR LIGHT	ACTION
TEST	Blue	Simulates the sounds that rodents hear, proving that the product works normally.
ULTRA	Blue	22-35kHz conversion ultrasonic frequency
TRANS	Green	25kHz ultra solid ultrasonic frequency
DUO	Blue + Green	Both ultrasonic waves operate at the same time

SETTING LED STROBE LIGHTS

Press the LED On/Off button on the back of the unit to enable the flashing lights function.

IMPORTANT: The strobe lights only work at night, they will not function during the day or if the light sensor detects too much ambient light.

At night, the flashing lights automatically cycle through three modes, each working for 30 seconds.

To turn the light function OFF, press the LED button again.



Do not use this appliance if any part of it has been underwater. Immediately call a qualified service technician to inspect the appliance and replace any part of the electrical system which has been under water.



SAFETY STATEMENTS & WARNINGS

- For indoor use only.
- Do not disassemble, repair or alter this unit in any way. No user serviceable parts.
- Do not drop, as doing so can permanently damage internal components.
- Do not use in high-traffic locations such as areas where children and pets play.
- Never use chemicals or abrasive materials to clean the unit.
- Do not use near pets that may be affected by the ultrasonic frequency.
- Supervise children at all times in the proximity of this product.
- Do not allow children to operate this product.



This product contains electrical components. When the unit can no longer be used, it should be recycled in accordance with local laws and regulations. Do not dispose of this product with other household waste.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with operation or the product was damaged during shipping, please contact our customer service team through one of the methods mentioned at the top of page 1. Please have the item number and order information ready to expedite response time.

WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.