


ASSEMBLY INSTRUCTION



WARRANTY:

We warranty this product to be free from defects in materials. This warranty covers one year from the date of original purchase.

NOTES:


























- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

WARNING:

- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.


1

PARTS LIST

A	B	C	O	P	Q	R	S	T			
											
2PCS	1PCS	1PCS	1PCS	4PCS	4PCS	2PCS	2PCS	2PCS			
U	V	W	X	Z	a	b	d	f	k	t	u
											
2PCS	2PCS	4PCS	1PCS	2PCS	1/4*80 4PCS	1/4*50 8PCS	1/4*40 10PCS	1/4*19 4PCS	4PCS	4PCS	1/4 4PCS
v	w	x	y								
											
4PCS	10PCS	1/4 2PCS	2PCS								

2


NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED




3

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

3




4




4

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

5




6




5

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

7




8




6

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

9



10



Note: paste the "k" fitting on the surface of the "R" fitting, as shown in the picture in the middle of the "R" fitting.