
ASSEMBLY INSTRUCTIONS

- CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
- 2. SCREW THE TUBE(B) INTO THE BASE(A).
- 3. SCREW THE SOCKET SECTION(C) INTO TUBE(B).
- 4. PLACE THE HARP (D) INTO THE SADDLE OF SOCKET SECTION(C).
- 5. PUT THE SHADE (NOT INCLUDED) ONTO THE HARP (D) AND THEN FIX SHADE (NOT INCLUDED) WITH FINIAL (E) .
- 6. INSERT THE POLARIZED PLUG INTO OUTLET, THEN TURN ON THE SWITCH. YOUR NEW LAMP IS READY TO ENJOY.



WATTAGE: 75W TYPE A (BULB NOT INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.