



STEP 4

TURN 90°



Recommended Maximum Weight



*Unit in Pound(lbs.)

WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.




00:30

Approx. 30 minutes


Assembly Instruction

Furinno Moretti Modern Lifestyle TV Stand
for TV up to 50 Inch


MODEL : **FM19157**



Recomm. 2 Persons



No Tools Required



Customer Support

NEED HELP? For replacement requests or product inquiries, please contact our Customer Service Team by emailing us at support@furinno.com. Thank you for selecting Furinno!


www.furinno.com



HARDWARE & PARTS LIST

NO	HARDWARE LIST	QTY
A	LONG SCREW	8pcs
B	SHORT SCREW	14pcs
C	FLAT HEAD SCREW	4pcs
D	ALLEN KEY	1pc
E	RUBBER STUD	6pcs

NO	PARTS LIST	QTY
1	METAL FRAME A	1pc
2	METAL FRAME B	1pc
3	METAL FRAME C	1pc
4	UPPER RAIL	2pcs
5	BOTTOM RAIL	2pcs
6	TOP PANEL	1pc
7	LARGE SHELF PANEL	1pc
8	SMALL SHELF PANEL	1pc



USEFUL HINTS BEFORE YOU START:

- 1. Read each step carefully before assembling.
- 2. It is important that each step is performed in correct order to avoid difficulties.
- 3. Identify, sort and count the parts before assembly.
- 4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
- 5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
- 6. Using incompatible hardware might cause damage to product.

ASSEMBLY INSTRUCTIONS

BEFORE YOU BEGIN, PLEASE READ ASSEMBLY INSTRUCTION CAREFULLY, FOLLOW THEM STEP BY STEP.

REMINDER: Please do not fully tighten any screw until all of them are in right positions.

