















ASSEMBLY INSTRUCTIONS






													
A	24PCS	B	30PCS	C	20PCS	D	24PCS	E	6PCS	F	6PCS	G	18PCS
													
H	10PCS	I	10PCS	J	36PCS	K	6PCS	L	36PCS	M	8PCS	N	4PCS
													
O	2PCS	P	2PCS	Q	2PCS	R	2PCS	S	2PCS	T	2PCS	U	2PCS





1





2




3




4




5




6




7



8




9



x2




10







Adjust Right or Left

Adjust Up or Down

Adjust Forward or Back



11



x2

12

