




If there are any missing parts, damaged packaging or broken panels,
please contact our service email for assistance:


furni-service@outlook.com

CONTACT US!

Do Not return this product

If you encounter any missing parts, damaged packaging, or broken panels, please contact our customer service team for assistance:

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④















WhatsApp

For faster resolution:


① Include your **order number** ② Attach **clear photos** of the issue

We appreciate your patience and cooperation, and we'll do our best to resolve your concern promptly. Thank you!




A  75+2PCS	B  75+2PCS	C  Ø6*30MM 10+1PCS	D  Ø8*30MM 36+2PCS
E  M3.5*12MM 60+2PCS	F  M4*30MM 37+2PCS	G  12+1PCS	H  M3*16MM 12+1PCS
I  1PCS	J  4*35MM 1PCS	K  1PCS	L  4*12MM 1PCS
M  1PCS	N  1PCS	O  4PCS	P  10PCS

STEP 1





STEP 2





	A*26PCS		D*8PCS
---	---------	---	--------

STEP 3



	E*30PCS
---	---------


STEP 4



X2


	A*16PCS
---	---------

STEP 5





							L*1PCS
	A*2PCS		B*4PCS		D*4PCS		I*1PCS

STEP 6







	B*4PCS		D*4PCS
---	--------	---	--------


STEP 7



STEP 8




STEP 9




	A*4PCS		B*4PCS		D*8PCS
---	--------	---	--------	---	--------

STEP 10




	B*13PCS
---	---------

STEP 11





STEP 12




	B*13PCS
---	---------


STEP 13




	B*6PCS		F*2PCS
---	--------	---	--------




STEP 14




	F*6PCS
--	--------


STEP 15




	F*4PCS		M*1PCS		N*1PCS
---	--------	--	--------	--	--------

STEP 16




	O*4PCS
--	--------

STEP 17




	B*6PCS
---	--------

STEP 18





	G*12PCS		H*12PCS
---	---------	---	---------



STEP 19



STEP 20




STEP 21






X4

STEP 22






X4


STEP 23



STEP 24





STEP 25




	B*5PCS
---	--------

STEP 26



	E*6PCS
---	--------


STEP 27



THANK YOU!

Contact our friendly
customer service team first for help

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④



WhatsApp

If you have any questions, please leave the **order No.**
and **related picture** information, we will reply you
within 24 hours, and solve the problem as soon as possible.