

# ASSEMBLY INSTRUCTIONS



## TOOLS REQUIRED



Screwdriver
( Not included)




Allen Wrench



2 - People

## ASSEMBLY RATING



EASY ⟶ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

# CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




### Suitable Location

Assembling near the area of the intended location is highly recommended.




### Sufficient Space

Make sure you have enough space to move around during the assembly.



### Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



### Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE

**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**

# DINING TABLE



## PARTS

① 1PC




**Table Top**

② 2PCS






**Table Legs**

③ 2PCS




**Mounting Plate**

④ 1PC



**Leg Rail**

⑤ 2PCS



**Wood Block**

⑥ 1PC





**Table Leaf**


⑦ 2PCS



**Leaf Support Wood**


# HARDWARE

**A 24PCS**




**JCBC Bolt M6 X 40mm**

**B 28PCS**




**Spring Washer**

**C 28PCS**



**Flat Washer**

**D 4PCS**








**JCBC Screw M6 X 80mm**

**E 1PC**



**Allen Key M4**


# DINING TABLE is packed in 2 cartons

| Carton | Designation | Part | | Hardware |
|---|---|---|---|---|
| | Table Top (1pc) | 1 |  |  A 24 pcs |
| | Mounting Plate (2pcs) | 2 |  |  B 28 pcs |
| | Leg Rail (1pc) | 3 |  |  D 28 pcs |
| | Wood Block (2pcs) | 4 |  |  E 4 pcs |
| | Table Leaf (1pc) | 5 |  |  F 1 pc |
| | Leaf Support Wood (2pcs) | 6 |  | |
| | Table Legs (2pcs) | 7 |  | |

# ASSEMBLY INSTRUCTIONS


## 1

Part ② X 2pcs
Part ③ X 2pcs
Hardware Ⓐ X 12pcs
Hardware Ⓑ X 12pcs
Hardware Ⓒ X 12pcs
Hardware Ⓔ X 1pc




## 2


Part ① X 1pc
Part ⑦ X 1pc
Hardware Ⓐ X 4 pcs
Hardware Ⓑ X 4 pcs
Hardware Ⓒ X 4 pcs
Hardware Ⓔ X 1pc



# ASSEMBLY INSTRUCTIONS


## 3

Part① X 1pc
Part② X 2pc
Hardware Ⓐ X 8pcs
Hardware Ⓑ X 8pcs
Hardware Ⓒ X 8pcs
Hardware Ⓔ X 1pc




## 4


Part ① X 1pc
Part ② X 2pcs
Part ④ X 1pc
Hardware Ⓓ X 4pcs
Hardware Ⓑ X 4pcs
Hardware Ⓒ X 4pcs
Hardware Ⓔ X 1pc



# ASSEMBLY INSTRUCTIONS


## 5

Part ① X 1pc
Part ② X 2pcs
Part ⑤ X 2pcs





## 6


Part ① X 1pc
Part ⑥ X 1pc



# ASSEMBLY INSTRUCTIONS

**7**



**ASSEMBLY COMPLETED**

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

**Keep this handy!**


Please retain this instruction manual and any order-related information for future reference.

**Lift, don't drag!**

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

**This product is intended for RESIDENTAL USE ONLY and not for commercial use.**

# ASSEMBLY INSTRUCTIONS




## TOOLS REQUIRED



Screwdriver
( Not included)




Allen Wrench



2 - People

## ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

# CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




### Suitable Location

Assembling near the area of the intended location is highly recommended.




### Sufficient Space

Make sure you have enough space to move around during the assembly.



### Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



### Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE

**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**


# DINING CHAIR




## PARTS

① 1PC



**Back Rest**

② 1PC



**Cushion Seat Frame**

③ 1PC



**Front Leg (Left)**

④ 1PC



**Front Leg (Right)**

⑤ 1PC



**Stretcher (Left)**


⑥ 1PC



**Stretcher (Right)**


## HARDWARE

**A 2PCS**




**JCBC Bolt M6 x 35mm**

**B 4PCS**




**JCBC Bolt M6 x 60mm**

**C 4PCS**




**JCBC Bolt M6 x 80mm**

**D 1PC**




**Allen Wrench M4**

**E 10PCS**




**Lock Washer**

**F 10PCS**



**Flat Washer**

**G 4PCS**



**Pan Head Screw M4 x 32mm**


# ASSEMBLY INSTRUCTIONS

## 1

**Part①x 1pc**
**Part②x 1pc**

**Hardware Ⓐ x 2pcs**
**Hardware Ⓒ x 4pcs**
**Hardware Ⓔ x 6pcs**
**Hardware Ⓕ x 6pcs**
**Hardware Ⓓ x 1pc**

***TIGHTEN SCREW 80%**





## 2

**Part③x 1pc**
**Part④x 1pc**
**Part⑤x 1pc**
**Part⑥x 1pc**

**Hardware Ⓑ x 4pcs**
**Hardware Ⓔ x 4pcs**
**Hardware Ⓕ x 4pcs**
**Hardware Ⓓ x 1pc**

***TIGHTEN SCREW 80%**




# ASSEMBLY INSTRUCTIONS


## 3

**Part⑤x 1pc**
**Part⑥x 1pc**
**Hardware Ⓖx 4pcs**

***TIGHTEN SCREW 100%**




## 4



**ASSEMBLY COMPLETED**

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

**Keep this handy!**
Please retain this instruction manual and any order-related information for future reference.

**Lift, don't drag!**
To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.