
# ASSEMBLY INSTRUCTION

20" x 25 ½" x 41 ½"H



#### List of Part For 1 Set

Code	Figure	Part	Qty.
01		Back Frame	1
<b>02</b>		Seat	1
03		Front Leg	2

#### List of hardware For 1 Set

Code	Figure	Hardware	Qty.
(a)	0	Hex. Bolt M6 x 80mm	4
<b>b</b>		Hex. Bolt M6 x 60mm	4
©	0	Hex. Bolt M6 x 40mm	2
(1)	0	Flat Washer	10
e	0	Spring Washer	10
<b>(f)</b>	5	Spanner 10mm	1



## Important Notes

- Keep all hardware parts out of reach of children.
- \* Must tighten screws periodically. With use screws will become loose. Check tightness of all screws every 6-8 weeks.
- \* Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatedly.
- \* Do not tighten all screw / bolt until all completely assembled.

- Notes Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials including staples & packing straps before you start to assemble.
- Do not tighten all screws / bolts until all completely assembled.

## Care And Maintenance

- \* The Touch of a soft cloth is all the maintenance your wood pieces will ever need.
- \* Never use harsh chemicals or abrasive cleaner as they could mark or destroy finish.