




Assembly Instruction

ACCENT CHAIR

NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

COMPONENT LIST


NO.	DRAWING	QTY	DESC
A		1	CHAIR
B		2	FRONT LEG
C		2	REAR LEG
D		4	GASKET

Please follow the drawings below to assemble the item.




Legs are stored at the bottom of the unit as shown with arrow sticker. Please take out the legs for assembly.


Step 1. Take out the legs from the bottom of the Chair.



Step 2. Attach front and rear legs onto the position at the bottom of the chair as shown in drawing, rotate the legs in order to tighten it to the proper position.(rear legs are with outward position).



Step 3.Completed



CARE INSTRUCTION FOR POLYESTER FURNITURE:

In order to maintain the original appearance of your Polyester furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage Polyester. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.
- Vacuum or wipe with a soft brush to remove dust.
- Clean Polyester with professional cleanser.