


Adjust the adjustable tube of the back, to find the suitable height. Your Lounge is ready for use.

This Lounge can only be used on a flat, level surface.

Step 3



To Close, first colse the leg under the seat, then close the other leg which under back, by hand.

## Care & Maintenance 0 Do not put hot items directly on furniture surface Do not clean furniture with harsh cleansers or polish. 0 To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended. Children should not climb or jump on the furniture. Do not write on furniture without a padded barrier to protect the surface. To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings. Not for commercial use. For residential use only . Stains may be removed with mild soap solution and damp cloth. Keep away from sources of ignition. Dust and pick-up spills using a clean, non-colored, lint-free cloth.