













# two-seater chair




**ASSEMBLY INSTRUCTION**

# Assembly Instruction

|                                                                                                            |                                                                                                             |                                                                                                            |                                                                                                              |
|------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| <b>A</b> × 1<br>          | <b>B</b> × 1<br>           | <b>C1</b> × 1<br>        | <b>C2</b> × 1<br>         |
| <b>D1</b> × 1<br>         | <b>D2</b> × 1<br>          | <b>J</b> × 1<br>         | <b>E1</b> × 2<br>         |
| <b>F1</b> × 2<br>         | <b>G</b> × 14<br><br>M6X30 | <b>K</b> × 2<br><br>M6X40 | <b>L</b> × 2<br><br>M6X50 |
| <b>H</b> × 22<br><br>M6 | <b>I</b> × 1<br>         | <b>J</b> × 1<br>       | <b>M</b> × 4<br>        |


1

If you find any missing parts, please let us know, and we will send them to you as soon as possible.




Tighten the screws to 80%; then fully tighten them after installation.

2




Tighten the screws to 80%; then fully tighten them after installation.

3




Tighten the screws to 80%; then fully tighten them after installation.

4




Tighten the screws to 80%; then fully tighten them after installation.

5




Tighten the screws to 80%; then fully tighten them after installation.

6




Tighten the screws to 80%; then fully tighten them after installation.

7



8



AFTER THE SPONGE OF THE SOFA HAS BEEN COMPRESSED FOR LONG TIME, IT IS NECESSARY TO GIVE A CERTAIN TIME TO RESTORE THE SOFA AND THE ESTIMATED TIME IS 48 HOUR

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY !!!

## WARRANTY

The Company promises to repair or replace any Company product or component that is found to be defective in material or workmanship within one (1) year from the date of original purchase so long as the original purchaser still owns it. This is the purchaser's sole and exclusive remedy. This warranty is subject to the provisions below.

Limitations:

- Upholstery on chairs is warranted for one year from date of purchase.
- Damage caused by the carrier in-transit is handled under separate terms.

Exclusions:

This warranty does not apply and no other warranty applies to:

- Normal wear and tear, which are to be expected over the course of ownership.
- Modifications or attachments to the product that are not approved by the Company.
- Products that were not installed, used, or maintained in accordance with product instructions and warnings.
- Products used for rental purposes.

Seating Usage: To the extent that a seating product is used in a manner exceeding this, the applicable warranty period will be reduced in a pro-rata manner.

A word about color variations, fabrics and finishes:

The Company does not warrant the color-fastness or matching of colors, grains, or textures of covering materials.

## Safety and Care Advice

- A. Keep children and animals away from the assembly area. This furniture contains small parts that could cause choking if swallowed.
- B. Keep all plastic wrapping materials away from babies and children to avoid danger of suffocation.
- C. Ensure that all packaging is disposed of carefully and responsibly.
- D. From time to time check that there are no loose fittings on the unit, re-tighten when necessary.
- E. Two people may be required for the assembly of this product.
- F. Damaged components may influence the safety and function of a product. Never use the product if any component is missing or defective.
- G. Once items are part of fully assembled there are not returnable unless faulty.
- H. This item is only intended for indoor use and designed for use by one person at a time, the suggestion maximum static load capacity less than 250lbs.
- I. Some items will be supplied with a wall fixing strap, which we recommend is used to secure the item to the wall, to prevent a child from accidentally pulling furniture over.
- J. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by in correctly installed or assembly furniture.
- K. Do not stand on the furniture or use it as a step stool or ladder as it may result in physical injury or damage to the product.
- L. Do not be expose this item to direct sunlight and never touch with sharp objects, which may cause damage to the product.
- M. Leather and Vinyl Coverings: Occasionally dust the leather or vinyl surface with a soft, clean cloth. For mild stains, combine water and a soft cloth. Wet the cloth and rub gently over the stain before wiping dry. For deeper stains, apply a mild soap to the cloth. Work into a lather and rub gently over the stain. Rinse with a damp cloth and wipe dry. Cleaning products may cause discoloration and should be tested in an inconspicuous location prior to use on the chair. Warranty does not cover adverse cleaning results or scratching or scuffing that occurs during normal use.
- N. Fabric Upholstery: Pay immediate attention to spills and vacuum regularly to maintain appearance. Cleaning products may cause discoloration and should be tested in an inconspicuous location prior to use on the furniure. This furniture should not be used for other than its intended purpose. Please regularly inspect this furniture for loose or missing screws, metal fatigue, cracks, broken welds, missing attachments and general instability. If this furniture is damaged or appears to be unstable or unsafe, immediately remove from service and replace or repair the item. Failure to follow these warning could result in serious injury.