



1. Unscrew the height adjuster screw.



2. Adjust the position of the two screws to the middle position.



3. Reinstall the regulator back.