





ASSEMBLY INSTRUCTION




Patio Dining Chair






RARTS LIST

LABEL		DESCRIPTION	QTY
A		Backrest	2
B		Seat Frame	2
C		Leg	8
D		Seat Cushion	2




HARDWARE LIST

LABEL		DESCRIPTION	QTY
1	 M6×55	Bolts & Washers	8
2	 M6×15	Bolts & Washers	24
3	 M6	Allen Wrench	1

1





2



3



Tighten the screws to 100% tightness



#3



4



Note: Each leg has an adjustable fortuneteller to help level your chair.