























Assembly Instructions




A  X2	B  X1	C  X1
D  X1	E  X3	F  X1
G  X1	H  X1	I  X1
K  X1	L  X1	M  X1
N  X2	O  X 2	P  X1
Q  X2	R  X 4	S  X 4
V  X1	T  M 6X30 X90	U  X1


1




2




3




4




5




6




7




8




9




10




11





12



13



14



15

