

ASSEMBLY INSTRUCTION


DAYBED






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Attached Left Arm(A), Right Arm(B), Back Rail (E), Front Rail(F), Connection Strap(M), Lock Washer(J), Flat Washer(K), Bolt(I), Bolt(H) by Allen Wrench(N).




Attached Back Rest(C), Flat Washer(K), Lock Washer(J), Bolt(G) to Left Arm(A) and Right



Attached Slats For Daybed(D) to Back and Front Rail (E&F) with Self-Tapping

Screw(L).



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.