## **Operating instructions**

- Suitable for cats weighing more than 1.5kg and less than 10kg.
- The cat litter does not exceed the height of the three anti pad in the bucket. Please unplug the power before adding sand each time, and plug in the power after adding sand. Or short press the cleaning key once after each sand addition to zero gravity.
- When moving the machine or system disruption occurs, unplug the power supply for about 10 seconds and then restart the machine.
- When the machine is abnormal in weighing, please check to ensure that the machine is not against the wall around and placed horizontally on the hard floor, and then shut down and restart.
- The machine is suitable for small granular cat litter, such as bentonite cat litter, zeolite cat litter, short granular tofu litter or mixed litter (tofu litter is recommended not to exceed 1.5MM in diameter).
- Do not place objects on top of the device.
- Do not push or pull the device to avoid device

Note: For more information, please refer to the Product Manual.

## **Button Description**

## WiFi button



- Reset network: Press and hold White light on: the for about 3 seconds
- Blinking yellow light: The Internet is being connected to
- connection is normal
- Yellow light on: Network status to be connected

## Cleaning button



- Cleaning cat litter function: Short press 🖶 for 1 second and the buzzer will sound to activate the clean function.
- Clear drum clean all cat litter function: Press 🖶 for 3 seconds and the buzzer will sound to activate the clear function.
- White light on: Product is working
- Blinking white light: Indicates that the machine is suspended (manually press the cleaning button to stop)
- Blinking yellow light: Gravity anti-clamp is triggered
- Yellow light on: Indicates that the collection bin is full and the infrared anti-clip trigger in the bin

材质:透明PVC薄膜,厚度0.1mm

背胶:单面,不干胶

字体:黑色

注:字体需印刷在背胶那一面