




















Parts List

A₁  4X40mm 38pcs	A₂  3x12mm 18pcs	B  1pc
A₃  4X25mm 4pcs	A₄  3x18mm 4pcs	
C  1pc	D  2pcs	E  1pc  3pcs 28PCS
G  4pcs	H  2pcs	I  2pcs
K  2pcs	L  2pcs	J  1pc M  1pc

Assembly Instructions

①  A₁ 7PCS 6PCS	②  A₁ 7PCS 6PCS
③  A₁ 4PCS 8PCS	③  A₁ 4PCS 8PCS
⑤  A₁ 8PCS A₄ 4PCS	⑥  A₁ 8PCS
⑦  A₃ 4PCS A₂ 18PCS	