



SKU:ODF-KID-PICNIC ASSEMBLY INSTRUCTION

Parts List:

A 6pcs 	F 4pcs 	G 2pcs 	
B 2pcs 			
C 1pc 			
D 2pcs 	E 2pcs 	H 16pcs 	J 38pcs

Assembly:

1

ATTENTION:
The edge with radian


2

ATTENTION:
The edge with radian


3

ATTENTION:
The edge with radian


4



5



6



WARNING :

- 1.This is not a toy-must be assembled by an adult.
- 2.Adult to read and follow these instructions and keep them for future reference.
- 3.Age Suitability-3 to 8 years.
- 4.Pls carry out checks and maintenance of main parts at regular intervals.If these checks are not carried out,the product may cause a fall or overturn.
- 5.Warning! Not suitable for children under 3 years due to small parts.
- 6.This item is not designed for children to stand or climb on.
- 7.Maximum weight capacity:100KGS.
- 8.This product should be used by children under the supervision of an adult.