

ASSEMBLY INSTRUCTIONS



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part # -Legs
- Part # -leg
- Part # -Body

Do not assemble if any of the following Hardware parts are missing:

- Part # -Bolt
- Part # -Alenkey
- Part # -Washer
- Part # -Washer lock

2 IMPORTANT SAFETY INFORMATION

Assembly Step If loosening persists, please **make sure to tighten all the bolts periodically.**

+Parts Included


① Legs 2 pcs



② Leg 1 pc



③ Body 1 pc



+Hardware Included

A Bolt
 $\frac{5}{16}$ "X25mm
12 pcs



B Alenkey
4X59mm
01 pc



C Washer
5/16x19x1.2mm
12 pcs



D Washer lock
5/16x12x1.2mm
12 pcs



ASSEMBLY INSTRUCTIONS

