




After successful installation  
please put the chair in a shady  
outside for 1-2 days.



For longer use

Re-tighten bolts every 6 months by using  
the enclosed allen-key.  
\*Using an electric drill can damage the chair.  
Please re-tighten bolts manually.



## Safety Information



Sit in the center of the  
chair, with your back to  
the backrest



Do not sit at the front  
edge of the chair



Do not stand on the  
chair



Do not use the chair  
with more than one  
person



Do not push the chair  
around when a person  
is sitting in it



Do not push down on  
the backrest when a  
person is reclined



Do not place all your  
weight on only the  
backrest

# INSTRUCTION MANUAL


Model: C-2077



# INSTRUCTION MANUAL

C-2077

## Package List




(1)\*1 Seat




(2)\*1 Back



(3)\*1 Gas Lift



(4)\*1 Base



(5)\*5 Casters




(6)\*2 Bolts




(7)\*1 Wrench


# Assembly Instruction




**1** Press the Casters (5)\*5 into the holes at the end of each Leg of Base (4).



**2** Insert the Gas Lift (3) into the center of the Base.




**3** Align Back with Seat, install Back (2) to the Seat (1) with Bolts (6)\*2.



**4** Align the center hole of the Seat (1) with Gas Lift (3) and press the Seat down until it is fully secured.

## Seat Height: Paddle-shaped lever on the right side



**To raise:**  
While taking your weight off chair, lift lever up.



**To lower:**  
While seated, lift lever up.

## CAUTION:

- \* Before using the chair, check to ensure that all bolts are fully tightened.
- \* Lubricate all parts and tighten all bolts every 6 months or whenever needed.