
ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED




Allen Wrench

(Included)



Phillips Screwdriver
(Not Included)



2 - Persons Recommended

ASSEMBLY RATING



EASY ——► DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 19-10-15

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling. Set up your workspace by laying the parts and hardware out separately, then begin!


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.





IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING TABLE










PARTS


#1 1pc	#2 4pcs	#3 2pcs	#4 1pc
			
Table Top	Leg	Leg Support Frame	Glass Strip

HARDWARE

#A 16pcs	#B 16pcs	#C 10pcs	#D 16pcs
			
Bolt ø 5/16" x 7/8"	Bolt ø 5/16" x 7/8"	Bolt ø 5/16" x 1-1/4"	Flat Washer ø 5/16" x19mm

#E 10pcs	#F 26pcs	#G 1pc	#H 8pcs
			
Flat Washer ø 5/16" x16mm	Lock Washer ø 5/16"	Allen Wrench	Bracket

#I 8pcs



Cover


ASSEMBLY INSTRUCTIONS

1

Part (#2) x4pcs
Hardware (#B) x16pcs
Hardware (#H) x8pcs

I. Align the two brackets (#H) with the pre-drilled holes of the leg (#2).
II. Secure the brackets (#H) using the Allen wrench (#G) to tighten the 4 bolts (#B) to lock them with the leg (#2).
III. Repeat the process above for the remaining 3 legs.

Turn right (clockwise) to tighten




X 4

2

Part (#1) x1pc
Part (#2) x2pcs
Hardware (#A) x8pcs
Hardware (#D) x8pcs
Hardware (#F) x8pcs

I. With the help of another person, carefully place the table top (#1) facing down on a protective surface. Align the brackets (#H) assembled onto the two legs (#2) with the pre-drilled holes on the table top (#1).
II. Prepare 8 bolt assemblies by inserting FIRST the lock washer (#F) onto the bolt (#A) and then the flat washer (#D) onto the SAME bolt (#A), in that order.
III. Insert the bolt assemblies through the holes of the brackets (#H) and secure those bolts using the Allen wrench (#G) to lock them with the table top (#1).

Turn right (clockwise) to tighten




ASSEMBLY INSTRUCTIONS

3

Part (#3) x2pcs
Hardware (#C) x4pcs
Hardware (#E) x4pcs
Hardware (#F) x4pcs
Hardware (#I) x4pcs


I. Align the two leg support frames (#3) with the two pre-drilled holes of the two legs (#2).
II. Prepare 4 bolt assemblies by inserting FIRST the lock washer (#F) onto the bolt (#C) and then the flat washer (#E) onto the SAME bolt (#C), in that order.
III. Insert the bolt assemblies through the pre-drilled holes of the leg support frames (#3) and secure those bolt using the Allen wrench (#G) to lock them with the two legs (#2). Once tighten, place the covers (#I) over the bolts (#C).



4

Part (#2) x2pcs
Hardware (#A) x8pcs
Hardware (#C) x4pcs
Hardware (#D) x8pcs
Hardware (#E) x4pcs
Hardware (#F) x12pcs
Hardware (#I) x4pcs

Repeat Step 2 and Step 3 to assemble the remaining 2 assembled legs (#2) onto the leg support frames (#3) and the table top (#1).




ASSEMBLY INSTRUCTIONS

I. With the help of another person, carefully place the table upright.
II. Align the glass strip (#4) with the pre-drilled holes of the table top (#1).
III. Prepare two bolt assemblies by inserting FIRST the lock washer (#F) onto the bolt (#C) and then the flat washer (#E) onto the SAME bolt (#C), in that order.
IV. Insert the bolt assemblies through the pre-drilled holes under the table top (#1) and secure those bolt using the Allen wrench (#G) to lock them with the glass strip (#4).

5


Part #4 x1pc
Hardware #C x2pcs
Hardware #E x2pcs
Hardware #F x2pcs

Make sure the table is rested on a flat surface and does not feel loose or wobbly. If it does, double check that the bolts/screws are secured and properly tightened.



6

To install the batteries (not included), remove the screw that holds the battery cover by using a Phillips screwdriver. Install new AA-size 1.5-volt alkaline batteries with correct polarity (+,−) by following the illustration inside the battery cover. Close the battery cover and tighten back the screw.



Caution:
* Use batteries of the same type.
* Do not mix old and new batteries.
* Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
* Do not use rechargeable batteries.
* Do not try to recharge non-rechargeable batteries.
* Remove exhausted or corroded batteries.
* If light is not used for more than a week, remove the batteries to prevent depletion and corrosion.

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.