
















# Instructions


NO	Description		QTY
A	Backrest		1
B	Chair Frame		1
C	Chair Legs		2
D	Seat Cushion		1
E	Casters (Wheels)		4
F	Cushion Cover		1
G	Pin		2
H	Decorative Cover		2
o	M8*60		2+1
i	M6*16		4+1
j	M6*20		4+1
k	M6*4		4+1
l	T-bar		1



1. Install the chair legs
2. Connect the B(Chair Frame) and the C (Chair Legs) with screw i (M6\*16) and k(M6\*4).



2. Install the Seat cushion
  - Insert the frame into the bottom of the D (cushion) , cover it with F (cushion cover), and connect it with screw j (M6\*20)



3. Install the Backrest
  - Connect the A(Backrest) to the D(Seat Cushion) and insert the G (Pin) then tighten it with screw o (M8\*60)
  - Put on the H (Decorative Cover).



4. Install the Casters
  - Insert the E (Casters) at the bottom to complete the installation.

**Please note: One additional screw of each type is provided in the kit as a spare, in case any parts are lost or damaged during assembly.**