

CAUTION: IMPORTANT SAFETY INSTRUCTIONS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

- **For indoor or outdoor use.** When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupter (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- This seasonal use product is not intended for permanent installation or use.
- Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Unplug the product when leaving the house,

when retiring for the night, or if left unattended.

- Do not let lamps rest on the supply cord or any wire.
- **CAUTION:** This is an electrical product – not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire or light string.
- Do not close doors or windows on the product or extension cords as this may damage the


wire insulation.

- Never operate this product if the power cord or plug is damaged.
- Read and follow all instructions that are on the product or provided with the product.

USE AND CARE INSTRUCTIONS

- When storing the product, carefully remove the product from wherever it is placed, avoiding any undue strain or stress on the product conductors, connections, and wires.
- When not in use, store neatly in a cool, dry location protected from sunlight.

Diagram 1



IMPORTANT NOTE: Some unassembled section pieces have light string wires strung between them. Be careful not to put unnecessary strain on the wires during assembly procedures. Light strings may be disconnected during assembly if necessary and reconnected upon assembly completion.

Assembly

Diagram 1 Attach the halves of angel bottom sections together by inserting rods into loops (A). Secure the halves together where rings meet using tie wraps supplied (B).

Diagram 2


1. Attach angel middle section to bottom section by inserting rods into loops (C). Secure the sections together where rings meet using tie wraps supplied (D).

2. Attach angel top section to middle section by inserting rods into loops (E). Secure the sections together where rings meet using tie wraps supplied (F).
3. Attach right wing by inserting rods into loops (G). Attach right arm by inserting rod into loop (H). Repeat process for left wing and left arm.
4. Attach trumpet by inserting rod into loop as shown (I). Rest arms on trumpet and lock in place by inserting hook at tip of right arm into frame of left arm (J).
5. Secure frame to the ground using the supplied metal stakes.

Operation

Connecting the plug to a power supply will immediately turn on the lights.

Diagram 2



SAVE THESE INSTRUCTIONS