


COFFEE TABLE

Instruction Manual



- Excellent weather resistance
- Easy to clean and maintain

Instruction Manual

ASSEMBLY INSTRUCTIONS:

- Our clear, easy-to-follow, step-by-step instructions will guide you through the project from start to finish.
- Do not skip any steps. It is of utmost importance to assemble all of the parts according to the directions.
- Item identification: For ease of identification, all parts are labeled to correspond to the step number in which the part is used.



IMPORTANT:


- Read following instructions carefully before using the table.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws (Insert all screws before tighten screws).
- Firmly secure all bolts, screws and nuts before use.
- Please do not exceed the weight limitations of this item.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.

CARE &SAFETY


- Always use on firm level ground.
- Keep all children and pets away from assembly area. Children and pets should be supervised while the product is being assembled.
- The assembled product should be located at least 6 feet (2m) from any obstruction such as fence, garage, house, overhanging branches, laundry lines or electrical wires.
- Do not use or store this item in the proximity of open flame or flammable/-combustible chemicals.
- In case of fire, do not attempt to extinguish any burning polypropylene with water.
- Please contact Customer Service if you have any problems or discover any missing parts.


ASSEMBLY PARTS



A 	B 
Legs: 2 pcs	Table panel: 1 pc



ASSEMBLY PARTS


①		②	
Allen wrench: 1 pc		M6*15 screws: 6 pcs	

③		④	
Nuts: 6 pcs		Wrench: 1 pc	




Installation Instruction

Invert the table panel(B), insert the support legs(A) into the table panel(B). Align the holes, insert the M6*15 screws(②) by allen wrench(①). And then lock the nuts(③) by wrench(④) until they are tight.



PAY ATTENTION

DO NOT EXCEED THE MAXIMUM LOAD OF *265LBS.*



DONE!

WARRANTY

3-year basic Warranty Program

- We offers a 3-year basic warranty on the entire table from the date of purchase against defects in material and workmanship. During this period we will repair and replace, at our discretion, the defective component.
- This warranty does not apply to improperly installed, handled, abused, damaged by user error, nor to any unit which has been repaired or altered by unauthorized repair companies.
- Under no circumstances will the customer entitled warranty to consequential or incidental damages. This limited 3-year basic warranty will only grant customers certain legal rights; customers may have other rights according to different state laws.