




ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED:

Allen Wrench (supplied, part # D)



BEFORE YOU START:

1. Check the parts against the parts list to make sure all items are present.
2. Assemble your furniture on a soft, flat surface to avoid scratching the finish.
3. **CAUTION:** Do not over tighten screws, nuts or bolts during assembly.
4. Your furniture may require occasional tightening.

INSTRUCTIONS:

1. Turn the table top upside down on a clean soft surface.
2. Attach two legs to the table using the Flat Washer (C), Lock Washer (B), Bolt (E) and the Allen Wrench (D). (Shown in Diagram 1)
3. Slide the bottom shelf into the slots on the legs, then attach the other two legs to the top panel using the Flat Washer (C), Lock Washer (B), Bolt (E) and the Allen Wrench (D). (Shown in Diagram 1)
4. Use the Bolt (A), Lock Washer (B), Flat Washer (C) and the Allen Wrench (D) to tighten the bottom shelf and Angle Bracket (F). (Shown in Diagram 2)
5. Tighten all bolts before using the table.




Diagram 1






Diagram 2



No.		Hardware List	Q'ty
A		1/4"x 5/8" Bolt	8pcs
B		1/4" Lock Washer	16pcs
C		1/4" Flat Washer	16pcs
D		1/4" Allen Wrench	1pc
E		1/4"x 2" Bolt	8pcs
F		Angle Bracket	4pcs

Thank you for purchasing furniture