




Instruction manual

urchasing our Illuminated Erasable LED Writing Board.

Instructions carefully for correct operation and usage.

Installation



Foot

Attention

Draw or write on the board with the included special fluorescent marker pen.

- 2) It is better to wipe when paint is dry.
- 3) Please keep board steady when wiping large area to prevent board from breaking.
- 4) It is easier and faster to wipe down the same direction as your painting and
- 5) Please use a wet cleaning cloth (wring out water) to wipe large area, then polishing with a soft dry cloth.

C. Usage for Control Box

- 1) After you are finished painting, please connect interface of control box to interface on the board, then connect the other interface of control box to power adapter.
- 2) Press the red button on control box for 3 seconds, your design on the board will turn up immediately. Repeat, press for 3 seconds, will turn off board.
- 3) Press the red button on control box to select different colors and flash, then press for one change.

D. Usage for Remote Control

- 1) To first usage of remote control remove the separation blade.
- 2) Aim the remote control at the receiver of control box.
- 3) Press the key to select the color and mode change.

3. Attention

- 1) You must use our appropriate power adapter (220V/12V, 1A), other type will cause permanent damage to the board.
- 2) The panel is acrylic material, do not strike or let fall.
- 3) Do not submerge in water and please keep away from rain to avoid short circuit.
- 4) Turn off the power when drawing on board to protect your eyes do not look into the light for long periods of time.
- 5) Please wring out wet cleaning cloth to prevent water seepage into the board and other security risks.