







Assembly Instructions





36 " ROUND SOLID FIXED TOP TABLE

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

COMPONENT LIST:

PART NO	FIGURE	DESCRIPTION	QTY
DB53636-01 DC33636G/R-01		Hardware Bag	1 pce
DB53636-13 DC33636G/R-13		Table Top	1 pce
DB53636-08 DC33636G/R-08		Stand	1 pce
DB53636-07 DC33636G/R-07		Leg	4 pcs
DB53636-18 DC33636G/R-18		Mounting Plate	1 pce
DB53636-22 DC33636G/R-22		Levelers	4 pcs

HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		Hex Nut	12 pcs
2		Lock Washer	12 pcs
3		Flat Washer	12 pcs
4		Wrench	1 pce


This product will take 15-20 minutes to assemble.

Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening

NOTE:

1. Two or two people are needed for assembly
2. Please keep all hardware parts out of the reach of children.




Assembly Instructions

36 " ROUND SOLID FIXED TOP TABLE

ASSEMBLY :


STEP 1

- 1.1-Turn the Stand upside down on a soft protective surface. Attach Leg by inserting leg through per-drilled holes on.
- 1.2-Use **Flat Washer(3)**, **Lock Washer(2)**, **Hex Nuts (1)** and **Wrench(4)** to attached the Leg to the stand.
- 1.3-Repeat step 1.2 For the remaining legs Leg, once all leg been attached, turn the base assembly right side up.




STEP 2

- 2.1-Align and attach the table top to the base Assembly by inserting **Flat Washer(3)**, **Lock Washer(2)** and **Hex Nut (1)**, tighten all nuts using **Wrench(4)** provided.



STEP 3

- 3.1- Adjust the levelers until the table sits firmly.



CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.