












ASSEMBLY INSTRUCTION




CARTON CONTENT

Ⓐ x4 	Ⓑ x2 	Ⓒ x1 
Ⓓ x2 	Ⓔ x2 	Ⓕ x2 
Ⓖ x2 	Ⓗ x4 	Ⓘ x28  M6*15
Ⓙ x8  M6*30	Ⓚ x8  M6*40	Ⓛ x4  M6*55
Ⓜ x48 	Ⓝ x1 	Ⓞ x1 


STEP 1

- Ⓐ X4
- Ⓑ X2
- Ⓙ X8
- Ⓜ X8





STEP 2

- Ⓒ X1
- Ⓢ X4
- Ⓜ X4




STEP 3

Ⓝ X1





STEP 4





STEP 5 x2

- Ⓕ X1
- Ⓖ X1
- Ⓚ X2
- Ⓜ X2





STEP 6 X2

- Ⓔ X1
- Ⓘ X2
- Ⓚ X1
- Ⓛ X1
- Ⓜ X4





STEP 7 X2

- Ⓓ X1
- Ⓘ X2
- Ⓚ X1
- Ⓛ X1
- Ⓜ X4





STEP 8 X2

- ⓗ X2
- Ⓘ X8
- Ⓜ X8



STEP 9 X2



STEP 10

