



Assembly Instructions

3 Pieces Outdoor Wicker Sectional Conversation Set




1	Lounge Sofa	3	Coffee Table
2	Loveseat Sofa		


HARDWARE INCLUDED



#1




#2




#3



BB




CC



DD



EE

















FF



GG

Part	Description	Quantity	Part	Description	Quantity
#1	Allen Wrench	2	DD	M6*50 Bolt	18
#2	Ratchet Wrench	1	EE	Nut	18
#3	Hex Wrench	2			
BB	Washer	60	FF	Adjustable Feet	13
CC	M6*35 Bolt	24	GG	"V" Clip	2

PACKAGE CONTENTS

Part	Description	Image	Quantity	Part	Description	Image	Quantity
A	Lounge Sofa Right Arm		1	J	Coffee Table Top		1
B	Lounge Sofa Backrest		1	K	Coffee Table Side		2
C	Lounge Sofa Seat		1	L	Coffee Table Front/Back		2
D	Lounge Sofa Side		1	M	Ottoman Cushion		1
E	Lounge Sofa Front Loveseat Sofa Side		2	N	Back Cushion		3
F	Loveseat Sofa Left Arm		1	O	Armrest Cushion		2
G	Loveseat Chair Backrest		1	P	Seat Cushion		3
H	Loveseat Sofa Seat		1				

