
















ASSEMBLY AND OPERATING INSTRUCTIONS

844-219




For Garden arch


Part#	Figure	Qty
A		2
B		2
C		2
D		2
E		8
F		6
G	 M5	1

Part#	Figure	Qty
H1	 M5 × 15	12
H2	 M6 × 20	8
H3	 M6 × 28	16
H4	 M6 × 45	4+1
Z	 M6	1


1.




2.



3.



4.



Note:

After assembling, insert 4 feet into the lawn or the ground. In order to fix the arch, the foot tube should be inserted into the lawn or ground at least 10cm.