


Installation Manual



1	PRE-INSTALLATION PREPARATION	01
1-1	Thank you for choosing our products	01
1-2	Package contents	01
1-3	Precautions	01
2	CUSTOMER SERVICE	02
3	INSTALLING MODULES	03
3-1	Product Assembly Diagram	03
3-2	Suggestion	04
3-3	Parts List	05
3-4	Assembly Steps	06
4	PROBLEMS YOU MAY ENCOUNTER	13

Thank you for choosing our products

Before assembly, please read this Installation Manual first, and check according to Parts List to make sure all parts are included.

Our contact e-mail is VIPService68@outlook.com. Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority.

Package contents

Fabric dresser with drawers

Assembly tools

Installation Manual

Precautions



Avoid long-term direct sunlight exposure.



Keep away from sharp objects.



Keep away from corrosive substances.




Keep assembled parts away from infants/children to avoid accidental ingestion.



This product must be assembled by an adult before use.



Never allow children to stand, climb or hang on drawers, doors or shelves.



Note that the wall to be drilled has no hidden electrical wires, water pipes and gas pipes.



When assembling the product, be careful of iron frames or iron pipes hitting people.



Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.

Quick Response within 24 Hours




If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video and photograph, which illustrates your product issues.

Contact Us

Separate and count all parts and hardware, if parts are missing, defective or there are wrong parts in the package, or missing some screw holes. You can contact us by scanning the QR code below, we will reply you in time.




How the knock down assembly system works




How to Install Wood Dowel


Insert the wood dowel [F] at least half way by tapping lightly with a rubber mallet, IF NECESSARY.




Cam Lock System Operation



1. Screw the cam bolt [E] into the threaded insert on the panel.
2. Connect both panels together making sure cam bolt[E] goes into the pre-drilled large hole on the end of panel for cam lock[D].
3. Insert the cam lock[D] into the pre-drilled large hole on the panel. Make sure the cross slot of cam lock [D] faces out (The arrow should point towards Screw No. E).
4. Rotate the cam lock [D] clockwise with a self-supplied phillips screwdriver to lock the cam bolt [E] in place (Rotate 100-180 degrees until tight).



Product Assembly Diagram



Suggestion



00:30

The installation
takes 30 minutes



For convenience
and safety, we
recommend two
people to assemble















Assemble it by
selecting the drill
to our manual
mounting
specifications



Product assembly
video



Parts List

			
① x1	② x1	③ x1	④ x1
			
⑤ x1	⑥ x1	⑦ x2	⑧ x2
			
⑨ x1	⑩ x1	⑪ x2	



				
Ø6x32mm A x14+1	B x14+1	Ø6x30mm C x16+1	Ø3.5x12mm D x26+2	E x4
				
M5X40mm F x8	G x4	H x8	Ø3x16mm I x8	J x2
				
Ø6x30mm K x2	M4X35mm L x2	N x1	M3 M x1	O x2

Assembly Steps

STEP 1





STEP 2




Assembly Steps

STEP 3





STEP 4





Assembly Steps

STEP 5





STEP 6





Assembly Steps

STEP 7




STEP 8






Assembly Steps

STEP 9





STEP 10




Assembly Steps

STEP 11



STEP 12





Assembly Steps


STEP 13



Ø3.5x12mm **D** x16



STEP 14



PROBLEMS YOU MAY ENCOUNTER

PART	PROBLEM	SOLUTION
ALL Product	Parts are missing, defective or having wrong parts in package	You can contact us via purchasing platform or reach us via email: VIPService68@outlook.com, and we will get back to you within 24 hours.
	Having issue(s) while reading the instruction or completing the assembly.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Fabric Dresser Surface	Board Surface is broken, scratched or lack of some screw holes.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The screw holes that Table on the board and the Surface steel frame don't line up.	1.Please tighten the screws on the board by 70%, do not tighten completely. 2.Adjusting board and steel frame until the screw holes are lined up, then tighten all the screws.
	The fabric dresser is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the desktops are flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.
Steel Frame	The fabric dresser is uneven or not tight that has gaps after being assembled.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The product is unstable after being assembled.	1.Check if the screws are tightened. 2.Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3.If your problem still can't be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Drawer	Broken, dirty or missing	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.

WARNING



Children have died from furniture tip over. To reduce the risk of furniture tip over:

ALWAYS install tip over restraint provided.

NEVER allow children to stand, climb or hang on drawers, doors, or shelves.

NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

VIPService68@outlook.com

MADE IN CHINA