



Assembly Instructions


Thanks you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.




1. Open the package and take out all accessories.




2. Connect the two wooden handrails to the bottom bracket through A screws and lock them with an L-shaped wrench. Please note that the raised side of the armrest faces outwards and the side of the wooden base with right-angle hinges faces upwards.




3. Fix the right-angle hinge to the mark on the back of the cushion using B screws and screwdriver. Turn the product over to the front, fold the seat cushions to adjust to sofa mode, and place the cushions to complete the installation.



Parts list



4. Adjust the sofa to bed mode. Open the zipper on the back of the backrest and the seat cushion and take out the 3 pairs of hidden feet. Push the backrest forward 30 degrees and then put it back, and adjust the backrest to bed mode.



5. The backrest angle can be adjusted according to your preference. There are still several gears for you to choose from flat to 90 degrees. First push the backrest forward 30 degrees and then lay it flat. When adjusting to other gears, just lift the backrest up and stop when you hear a click sound.

