


ASSEMBLY TIPS



! WARNING:



- Do not allow children to climb on unit
- Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over, it must be permanently fixed to the wall. Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer
- Avoid sharp objects or corrosive chemicals to prevent damage to the product
- During assembly, keep parts and packaging materials away from children and pets as there could be potential injury and choking hazards

Caution:


1. This product is designed for home use and not intended for commercial use.
2. This product contains small components. Please ensure that they are kept away from small children.
3. Be careful when using power tools to assemble your furniture. Power tools may strip or damage the parts.

IDENTIFY PARTS


One unit per box



x3




x3



x3

IDENTIFY PARTS


1



1602×398×15mm

Top Panel ×1


2



1602×398×12mm

Upper Shelf Panel ×1


3



372×712×15mm

Partition Panel ×1


4



396×712×15mm

Left Side Panel ×1


5



396×712×15mm

Right Side Panel ×1


6



372×712×15mm

Partition Panel ×1


7



1542×61×15mm

Lower Bracket Panel ×2


8



313×61×15mm

Lower Bracket Panel ×3

9




524×212×15mm

Drawer Front Panel ×3


IDENTIFY PARTS

10




514×212×15mm
Drawer Front Panel ×3

11




514×212×15mm
Drawer Front Panel ×3

12



463×142×12mm
Drawer Back Panel ×9

13




349×142×12mm
Drawer Left Panel ×9

14



349×142×12mm
Drawer Right Panel ×9

15



512×61×12mm
Front Brace Panel ×6

16



512×51×12mm
Front Brace Panel ×3

17



512×146×15mm
Middle Back Panel ×2


18



512×146×15mm
Middle Back Panel ×1

IDENTIFY PARTS


19



470×345×3mm

Drawer Bottom Panel ×9


20



522×291×5mm

Back Panel ×1


21



522×291×5mm

Back Panel ×1

22




522×291×5mm

Back Panel ×4


IDENTIFY PARTS

A




M7x40mm
Cam Bolt&Lock x86

B




M7x40mm
Screw x16

C




M3.5x12mm
Screw x74

D




M4x35mm
Screw x36

E



Back Panel Wedge x24

F




M3.5x14mm
Screw x24

G




M8x30mm
Wooden Needle x18

H




14"
Left Drawer Slide x9

I




14"
Right Drawer Slide x9

J




14"
Left Drawer Slide x9

K



14"
Right Drawer Slide x9


O




Anti-tipping Kit x2

"A" Hardware installation example


I



II




III




ASSEMBLY STEPS

Installation requirements and accessories




STEP 1

Cam bolt(A) into the white hole of panel(7), connect panel(8), and secure with cam lock(A). (Pay attention to the direction of the foot nail).



ASSEMBLY STEPS


Installation requirements and accessories



B×8 PCS




STEP 2

Screw(B) passes through panel(2) and fixes panel(7).




ASSEMBLY STEPS

Installation requirements and accessories






STEP 3

According to the marked hole positions, screw(C) passes through slide(H) and is fixed on panel(4), and screw(C) passes through slide(K) and is fixed on panel(5).




ASSEMBLY STEPS

Installation requirements and accessories






STEP 4

According to the marked hole positions, screw(C) passes through slide(K) and is fixed on the left side of panel(3), while screw(C) passes through slide(H) and is fixed on the right side of panel(3).




ASSEMBLY STEPS

Installation requirements and accessories




STEP 5

According to the marked hole positions, screw(C) passes through slide(H) and is fixed on the right side of panel(6), while screw(C) passes through slide(K) and is fixed on the left side of panel(6).




ASSEMBLY STEPS

Installation requirements and accessories




G×6 PCS



A×10 PCS


STEP 6

Cam bolt(A) into the white holes of panel(3) and panel(6), insert wooden needle(G) into the holes of panel(3) and panel(6), connect the ends of panel(15), panel(16), and panel(18) to panel(3) and panel(6), and fix them with cam lock(A).




ASSEMBLY STEPS

Installation requirements and accessories




G×6 PCS



A×10 PCS

STEP 7

Cam bolt(A) into the white hole on the other side of panel(3) and panel(6), insert wooden needle(G) into the hole on the other side of panel(3) and panel(6), connect panel(15), panel(16), and panel(17), and secure with cam lock(A).




ASSEMBLY STEPS

Installation requirements and accessories




G×6 PCS



A×10 PCS

STEP 8

Cam bolt(A) into the white holes of panel(4) and panel(5), insert wooden needle(G) into the holes of panel(4) and panel(5), connect the sides of panel(15), panel(16), and panel(17), and secure with cam lock(A).




ASSEMBLY STEPS

Installation requirements and accessories


STEP 9

Insert panel(22) into slots panel(3), panel(4), panel(5), panel(6), panel(17), and panel(18).



ASSEMBLY STEPS


Installation requirements and accessories



B×8 PCS

STEP 10

Screw(B) passes through panel(2) and is fixed at the bottom of panel(3), panel(4), panel(5), panel(6), with panel(22) inserted into the slot of panel(2).




ASSEMBLY STEPS

Installation requirements and accessories


STEP 11

Insert panel(20), panel(21), panel(22) into slots
panel(3), panel(4), panel(5), panel(6). (Pay attention
to the direction of the gap)




ASSEMBLY STEPS

Installation requirements and accessories





STEP 12

Cam bolt(A) into the white hole of panel(1), connect panel(3), panel(4), panel(5), panel(6), and secure with cam lock(A).





ASSEMBLY STEPS

Installation requirements and accessories




STEP 13

Insert E into the gaps of panel(20), panel(21), panel(22) and secure with screw(F).




ASSEMBLY STEPS

Installation requirements and accessories



STEP 14

Screw(D) passes through panel(13), panel(14) and is fixed on panel(12).




x9

ASSEMBLY STEPS

Installation requirements and accessories

STEP 15


Insert panel(19) into slots panel(13), panel(14), and panel(12).



x9


ASSEMBLY STEPS

Installation requirements and accessories



STEP 16


Cam bolt(A) into the white hole of panel(9), connect panel(13) and panel(14), and secure with cam lock(A).




×3

ASSEMBLY STEPS


Installation requirements and accessories



J×3 PCS




I×3 PCS



C×12 PCS


STEP 17

Flip the drawer over, place slide(J) at panel(14) and slide(I) at panel(13), follow the marked holes, and secure with screw(C).




ASSEMBLY STEPS

Installation requirements and accessories



STEP 18


Cam bolt(A) into the white hole of panel(10), connect panel(13) and panel(14), and secure with cam lock(A).




×3

ASSEMBLY STEPS


Installation requirements and accessories



J×3 PCS




I×3 PCS



C×12 PCS


STEP 19

Flip the drawer over, place slide(J) at panel(14) and slide(I) at panel(13), follow the marked holes, and secure with screw(C).




ASSEMBLY STEPS

Installation requirements and accessories




STEP 20

Cam bolt(A) into the white hole of panel(11), connect panel(13) and panel(14), and secure with cam lock(A).




ASSEMBLY STEPS


Installation requirements and accessories



J×3 PCS




I×3 PCS



C×12 PCS


STEP 21

Flip the drawer over, place slide(J) at panel(14) and slide(I) at panel(13), follow the marked holes, and secure with screw(C).




ASSEMBLY STEPS

Installation requirements and accessories




STEP 22

Measure distance, drill holes on the wall, insert anti-tipping kit(O2) into the wall, and fix anti-tipping kit(O3) through anti-tipping kit(O1) in anti-tipping kit(O2).



ASSEMBLY STEPS


Installation requirements and accessories



Cx2 PCS

STEP 23

Align the shelves with anti-tipping kit(O1) and secure anti-tipping kit(O1) and panel(1) on the inside with screw(C).




ASSEMBLY STEPS

Installation requirements and accessories

STEP 24

Insert the drawers into the shelves according to their numbers.



Supplementary Instructions for Safe Use

English

WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.
- Do not defeat or remove the drawer interlock system.

This is a permanent label.

Do not remove!

French

ATTENTION



Des enfants sont morts du basculement des meubles. Pour réduire le risque de basculement des meubles:

- TOUJOURS installer la retenue de basculement fournie.
- NE JAMAIS mettre de téléviseur sur ce produit.
- NE JAMAIS permettre aux enfants de se tenir debout, de grimper, ou de s'accrocher à des tiroirs, des portes ou des étagères.
- N'ouvrez JAMAIS plus d'un tiroir à la fois.
- Placez les objets les plus lourds dans les tiroirs les plus bas.
- Ne désactivez pas et ne retirez pas le système de verrouillage du tiroir.

Ceci est une étiquette permanente.

Ne pas enlever!

German

WARNUNG



Kinder sind an einem Möbelkipp gestorben. So verringern Sie das Risiko eines Umkippens von Möbeln:

- Installieren Sie IMMER die mitgelieferte Kipprückhaltevorrichtung.
- Stellen Sie NIEMALS einen Fernseher an dieses Produkt.
- Lassen Sie Kinder NIEMALS an Schubladen, Türen oder Regalen stehen klettern oder hängen.
- Öffnen Sie NIEMALS mehr als eine Schublade gleichzeitig.
- Legen Sie schwerste Gegenstände in die untersten Schubladen.
- Besiegen oder entfernen Sie das Schubladenverriegelungssystem nicht.

Dies ist ein dauerhaftes Etikett.

Nicht entfernen!