-FINIAL (E) SHADE (D) HARP (C) **BULB** (B) SADDLE (neck&socket)

ASSEMBLY INSTRUCTIONS

- 1. Assemble the socket Assembly (B) to the Base (A)
- 2. INSERT HARP (D) INTO SADDLE (B).
- 3. PLACE SHADE (E) ONTO HARP (D) AND TIGHTEN IT BY FINIAL (F).
- 4. PLACE BULB (C) (BULB NOT INCLUDED) ONTO THE SOCKET.
- 5. PLEASE USE MAX 3-WAY 150W TYPE "A" BULB. (BUT BULB NOT INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS

CAUTION: THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.