


CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.


NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List



Product Dimensions: 43.3"W×21.65"D×29.53"H



HW1x1 	HW2x16 	HW3x8  6x85mm	HW4x2  6x45mm	HW5x4  6x32mm	HW6x12  6x12mm	HW7x16  Ø7.8x30mm
HW8x2  6x45mm	HW9x2  Ø15	HW10x8  4x35mm	HW11x8  6x27mm	HW12x8  Ø12		


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 60 minutes.

1




X4

2




X2


3




4




5




6




7





8





9





10





11



12



13



14

