Heating Pad
- FOR PERSONAL USE ONLY –

SKU: A70-HP-001-SB

IMPORTANT NOTE

Read the entire manual carefully before using this device.

IMPORTANT
SAFETY INSTRUCTIONS
DO NOT DESTROY

When using this or any other electrical appliance, always follow these basic safety precautions:





DANGER-- To reduce the risk of burns, electric shock and fire, this product must be used in accordance with the following instructions.

1. READ ALL INSTRUCTIONS.
2. DO NOT USE WHILE SLEEPING.
3. NEVER LEAVE THIS APPLIANCE UNATTENDED, ESPECIALLY IF CHILDREN ARE PRESENT.
4. DO NOT USE ON AN INFANT.
5. DO NOT USE ON AN ANIMAL.
6. THIS PAD IS NOT SUITABLE FOR THOSE PERSONS, WHO ARE WITH POOR BLOOD CIRCULATION OR UNCONSCIOUS PERSON.
7. THIS PAD IS NOT TO BE USED ON A PERSON WITH DIABETES.

8. DO NOT USE ON AREAS OF INSENSITIVE SKIN.
9. BURNS MAY OCCUR REGARDLESS OF THE CONTROL SETTINGS, PLEASE CHECK THE SKIN UNDER PAD FREQUENTLY.
10. DO NOT USE PINS OR OTHER METALLIC THINGS TO FIX THE PAD.
11. DO NOT SIT ON OR PRESS THE PAD.
12. PUT THE PAD ON TOP OF THE BODY, NOT UNDERNEATH THE BODY. BECEASE THE HEAT LEVEL MAY INCREASE, WHEN HEAT IS TRAPPED.
13. NEVER USE LINIMENTS, OINTMENTS OR SALVES TO THE SKIN, ESPECIALLY THOSE CONTAINING HEAT-PRODUCING INGREDIENTS, WHEN USING PAD, AS SKIN BURNS COULD RESULT.
14. NEVER PULL THIS PAD THROUGH THE SUPPLY CORD.
15. NEVER UNPLUG THE PAD FROM THE ELECTRIC SOCKET WITH A WET HAND.
16. IF USING AN EXTENSION CORD FOR THIS PAD, THE MARKED ELECTRICAL RATING OF THE EXTENSION CORD SHOULD BE AS GREAT AS ELECTRICAL RATING OF THE PAD (SEE ELECTRICAL SPECIFICATIONS SECTION). THIS PAD CAN BE USED ONLY ON A 120 VOLT AC ELECTRICAL OUTLET. UNPLUG THE PAD FROM SOCKET WHEN NOT IN USE.
17. DO NOT USE THE ELECTRIC CORD AS A HANDLE.
18. PLEASE EXAMINE THE INNER VINYL PAD CAREFULLY EVER TIME, BEFORE USING. PLEASE DISCARD THE PRODUCT IF THE INNER VINYL PAD SHOWS ANY SIGN OF DETERIORATION.
19. DO NOT BEND OR PINCH THE CORD, AND DO NOT USE THIS PAD IF IT HAS A DAMAGED POWER CORD OR PLUG, HAS MALFUNCTIONS, HAS BEEN DROPPED, OR IS DAMAGED. THIS PAD SHOULD NOT BE REPAIRED BY YOURSELF. IF FOR ANY REASON THIS PAD DOES NOT FUNCTION SATISFACTORILY, PLEASE FOLLOW THE WARRANTY IN SERVICE INFORMATION.
20. DO NOT STEP ON THIS PAD IN ANY WAY.
21. COMBINE THE CORDS INTO A BUNDLE LOOSELY, WHEN STORING, TIGHT WRAPPING MAY DAMAGE THE CORD AND THE INTERNAL PARTS.
22. THIS PRODUCT IS INTENDED FOR PERSONAL USE, BUT NON-COMMERCIAL, NON-INDUSTRIAL USE. DO NOT USE THIS PRODUCT OUTDOORS OR FOR ANY OTHER PURPOSE.
23. PLEASE SAVE AND KEEP THESE INSTRUCTIONS.

This heating pad has a polarized plug (one blade is wider than the other), considering about safety. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, please contact with a qualified electrician.



DO NOT ATTEMPT TO DEFEAT THIS SAFETY FEATURE.

WARNING: Do not use this product if the Controller or Pad Connectors are wet. Make sure the product connections are completely dry before using.

Turn the product off by pressing the On/Off Button and unplug it when it is not in use.

Care and Maintenance

1. Disconnect the power cord from the electrical outlet.

2. Disconnect the heating Pad with the Control Connector, through pulling the Control Connector from the Pad connector.

3. The Pad without Controller can be washed by washing machine or hand, but using a mild detergent, cool water, and a gentle cycle.

4. Dry with a rope or lay the pad flat to dry, or tumbled dry on low heat.

5. Make sure the product is completely dry before the next use, especially the connector of the pad should be totally dry.

6. To store the product, please loosely roll the Heating Pad together, loop the cord over the rolled ends, and then store it in a cool, dry, dark location after each use. Avoid sharply folding the Heating Pad.

Electrical Specifications

Voltage	Frequency	Wattage	Amperage
120 VAC	60 Hz	85W	0.7A

Frequently Asked Questions

1. When can a heating pad be used?

When temporery hot is desired by personal comfort.

2. What temperature does this product reach?

Maximum temperature does not exceed the Underwriters Laboratories temperature limit of 176 °F (80 °C), when set to “Hi”. Temperature varies by heat setting; you can use a lower heat setting, but depending on the specific application and your personal preference.

3. How much time does it take to warm up to each temperature?

Temperature Selection	Indicator	Heat Up Elapsed Time
Low	1	6 min
Med	2	8 min
High	3	10 min