

NOTICE

*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

*This item may require periodic tightening.

PREPARATION

*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.











*Estimated Assembly Time: 30 minutes.

* Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE


*Store outdoor furniture indoors or cover well when not in use. Remove wooden furniture from standing water. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Chair		2x
B	Chair Seat		2x
C	Chair Leg		2x
D	Table Top		1x
E	Table Leg		2x
F	Table Glass		1x
HW1	Hexagon Socket Screw 6x0.5x150mm		16x
HW2	Hexagon Socket Screw 6x0.5x350mm		10x
HW3	Flat Washer 6mm		26x
HW4	Allen Key		1x

Item Dimensions Chair:
26.4"x29.3"x31.9"

Table: 18.5"x18.5"x19.3"



 **WARNING** 

Weight Capacity:
1 Seater: 220LBS
Table: 110LBS
Warning: Do not stand on item
Warning: Do not over torque bolts

PREPARATION


*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.

*Estimated Assembly Time: 30 minutes.

*Tools Required for Assembly (included): Allen Key


*Gradually tighten bolts in a star pattern: tighten one bolt and then the one opposite from it until all bolts are tightened.



STEP1:
Assemble the seat(B) to the chair(A),
using bolt and washer(HW2&HW3) and Allen key(HW4).





STEP2:
Assemble the leg(C) to the chair(A),
using bolt and washer(HW1&HW3) and Allen key(HW4).



STEP3:
Put the cushion and back cushion to the lovesofa.

PREPARATION

- *Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *Estimated Assembly Time: 30 minutes.
- *Tools Required for Assembly (included): Allen Key
- *Gradually tighten bolts in a star pattern: tighten one bolt and then the one opposite from it until all bolts are tightened.

 <p>The diagram shows three hardware items: HW4 (an Allen key), HW1 (a bolt), and HW3 (a washer). To the right, a table leg (E) is being attached to the table top (D). The leg is shown being inserted into a pre-drilled hole in the table top, with the bolt (HW1) and washer (HW3) being used to secure it. The Allen key (HW4) is used to tighten the bolt.</p>	 <p>The diagram shows the table top (F) with a glass being placed on it. A downward-pointing arrow indicates the direction of the glass being placed onto the table top.</p>
<p>STEP4: Assemble the table legt(E) to the table top(D), using bolt and washer(HW1&HW3) and Allen key(HW4).</p>	<p>STEP5: Put the glass to the table top.</p>