

Assembly

READ THE MANUAL CAREFULLY BEFORE USE.

ATTENTION:

THIS IS NOT A TOY! FOR DECORATIVE PURPOSE AND SEASONAL USE ONLY.

Features:

Indoor and Outdoor use

1.8 m (6 ft) high

320 cool white LEDs

Content:

- a. Top trunk
- b. Bottom Trunk
- c. Base
- d. Metal lawn stakes
- e. UL listed indoor/outdoor adaptor

Assembly:

Turn the bottom trunk clockwise into the base.


Insert the top trunk into the bottom trunk.

Stretch the branches.

For indoor use on any flat surface.

For outdoor use on the ground or lawn, secure the tree with the supplied stakes. If using an alternate surface, the consumer will secure the tree using their own fasteners.

Connect the adaptor with the tree lights' power cord by plugging the 2 pins on the male plug at the end of the power cord to the adaptor's female pinhole plug at the adaptor's end. Tighten the watertight cap to secure the connection.



ATTENTION:

DO NOT PLACE THE TREE CLOSE TO HEAT OR FIRE SOURCES OR HEATERS.

UNPLUG THE TREE DURING SEVERE WEATHER STORMS.

ONLY POWER THE TREE WITH THE SUPPLIED ADAPTOR.

THE LAWN STAKES MUST HOOK ON THE EDGE OF THE TREE STAND.