

ASSEMBLY INSTRUCTIONS



Dining Table

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


A	TOP		1PC	C	SIDE LEG		2PCS
B	MOUNTING PLATE		1PC	D	MIDDLE PANEL		1PC

HARDWARE IDENTIFICATION


1	ALLEN WRENCH (5MM - BLK)		1PC	4	LOCK WASHER (Ø5/16" -BLK)		16PCS
2	ALLEN BOLT (Ø5/16 x 1-1/2" - BLK)		12PCS	5	FLAT WASHER (Ø5/16" x 19MM- BLK)		16PCS
3	ALLEN BOLT (Ø5/16 x 2" - BLK)		4PCS	6	PLASTIC COVER (Ø 20MM-BLK)		4PCS

ASSEMBLY INSTRUCTIONS


STEP 1





STEP 2




STEP 3



STEP 4
COMPLETE





Note : Dimension tolerance $\pm 5\%$