



4-ARM HANGING BASKET STAND

Read all assembly and care instructions carefully before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

No.	PARTS		QTY.
A		Base Bracket	1
B		Leg	3
C		Foot	3
D		Bottom Pole	1
E		Top Pole	1
F		Arm	4

RECOMMENDED TOOLS (not included)	
	Wrench



 WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.


ASSEMBLY

STEP 1

A: 1

C: 3

TIP: Assemble the stand at the location it will be used; this unit does not require hardware to secure the legs and poles to the base and will disassemble if lifted by the pole.



Loosen the bolts on Base Bracket (A).
Install three Feet (C) into the base bracket.


STEP 2

B: 3

D: 1




Assistance is recommended for this step.



Install Legs (B) into the feet and Bottom Pole (D).
Tighten the bolts on the base bracket.

STEP 3


E: 1



Place Top Pole (E) onto the bottom pole.

STEP 4

F: 4



Insert Arms (F) into the top pole.

CARE & MAINTENANCE

SAFE USE: For residential use only. Only use on a flat, level surface.

When hanging items on the stand, ensure weight is evenly distributed to prevent tipping.

If the unit is used in windy locations, consider anchoring or putting weights on the base to prevent tipping (anchors/weights not included).

CLEANING: Wipe with a soft, dry or slightly damp cloth. Do not use harsh chemicals, abrasive materials or a pressure washer to clean the unit.

WINTER CARE & STORAGE: Store in a dry, indoor location.

SCRATCHES: The powder coating on the item is tough and durable; however, even with normal use, some scratching is inevitable. Scratches can be repaired with a rust-resistant paint (not included).

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS
CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, OR TOUCH-UP PAINT.

SAFETY STATEMENTS & WARNINGS

- Do not overload or exceed the weight capacity of the arms.
- Ensure weight is evenly distributed on each arm to prevent tipping.
- Do not move the stand while in use.
- Do not climb on the unit.
- Do not use harsh chemicals or abrasive materials to clean the unit.
- Store indoors during the winter and severe weather conditions.

Any modification to the product or failure to follow recommended care will void the product warranty.

*If you experience issues with assembly or the product was damaged during shipping,
please contact our customer service team through one of the methods mentioned at the top of page 1.
Please have the item number and order information ready to expedite response time.*

WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.