


Assembly Instruction

Note:


1. Should be assembled on flat ground to keep balance.
2. Before completing the installation, do not tighten the screws.




It needs at least two people to install.



Before starting the assembly, you must read the whole manual and follow the instructions



Assembly Instruction of Bed




Assembly Instruction of Bed

Hardware parts


A 1/4x13  8 PCS	B 1/4x35  6 PCS	C 5/16x19  4 PCS	D 5/16x34  12 PCS	E 5/16x55  4 PCS	F M3x13  2 PCS	G 5/16x48  6 PCS	H 1/4x45  8 PCS	I 1/4  1 PC
---	---	--	---	--	--	--	---	---

Assembly Instruction of Bed


Part list




1 2PCS




2 1PC



3 1PC




4 1PC




5 14PCS




6 1PC




7 1PC




8 2PCS




9 2PCS




10 2PCS




11 2PCS




12 1PC




13 4PCS




14 8PCS




15 2PCS




16 28PCS



17 1PC




18 1PC



19 1PC



20 1PC



21 1PC


Assembly Instruction of Bed

Step:1

A 1/4X13



8 PCS




Step:2

H 1/4X45



8 PCS





Assembly Instruction of Bed

Step:3

F M3x13



2 PCS






Step:4

G 5/16X48



4 PCS




Assembly Instruction of Bed

Step:5

B 1/4X35



6 PCS




Step:6

G 5/16X48



2 PCS



Assembly Instruction of Bed

Step:7

D 5/16X34




4 PCS

C 5/16X19



4 PCS



Step:8

D 5/16X34




8 PCS

E 5/16X55




4 PCS




Assembly Instruction of Bed

Step:9



LED lamp assembly details


Step:10




Secure the Led light strip with straps.

LED lamp assembly details

Step:11




NOTE: The black part of the receiver (20) needs to be exposed to air in order to better control the LED light.




Remote control

You can use the remote to control the light. The LED lamp can only be used after the power supply is connected.



Power cord



Please scan the QR code on the manual/controller and install the application.

Step1: Please make sure your phone has Bluetooth enabled.

Step2: The LED light will automatically connect to the APP.

