














ASSEMBLY INSTRUCTION (WF310565)






Part List (WF310565)

A  HEADBOARD - 1pcs	B  FOOTBOARD - 1pcs	C  SIDE PANEL - 4pcs
D  HEADBOARD LEG - 2pcs	E  WOODEN LEG - 4pcs	F  SIDE WOOD BASE - 4pcs
G  CENTER WOOD BASE - 2PCS	H  WOODEN SUPPORT LEG - 4pcs	I  SIDE PANEL SUPPORT - 2pcs
J  FOOTBOARD SUPPORT - 2pcs	K  STRAIGHT SLAT WITH HOLE - 4pcs	L  STRAIGHT SLAT - 6pcs


Hardware List (WF310565)

1




JB BB M8 x 16mm (8 pcs)

2




JB BC M6 x 35mm (20 pcs)

3




JB BC M6 x 45mm (12 pcs)

4




JB BC M6 x 60mm (4 pcs)

5




M6 Flat Washer (28 pcs)

6




CSK SCREW M4 x 30mm (8pcs)

7




Allen Key M4 (1pcs)

8




Allen Key M5 (1pcs)

9




BASE GLIDE (4pcs)




Assembly Tools
Required (Not Included)

Assembly Step


1




2



3




4




Assembly Step


5




6



7



8



Assembly Step

FULLY COMPLETED ASSEMBLY

