

Assembly Instructions


GAZ9701














Caution: Please read this before you proceed with assembly.

















Read all instructions before assembling and using this product

1. Select ideal location. Set out all parts on a clear and level surface prior to assembly. Ideally, the Gazebo should be set up in the desired location to avoid moving it after assembly.
2. Team Work. We recommend 3 adults and it may require 1 hours to fully assemble the Gazebo. If possible, please use safety ladders.
3. Use caution during the entire assembly process, especially when lifting large and heavy items. Also, use all safety precautions when using ladders. Keep children away from the assembly area.
4. Check all available parts. Before assembling the gazebo, check to make sure you have all the parts listed in the Parts List.
5. Important! Before attaching the canopy, make sure ALL BOLTS are tightened securely.
6. During assembly keep children away from the work area and the parts and tools. Once assembled, do not allow children to climb on the gazebo.
7. It is recommended that the Canopy, Sidewalls and Mosquito Netting be removed during strong winds and stormy conditions.
8. Do not set this gazebo up near electric lines, trees or slanted roofs. Use safety precautions at all times.


Gazebo



ITEM	DESCRIPTION	QTY.	ILLUSTRATION
A	Center Connector	1	
B	Long Left Lintel	2	
C	Long Right Lintel	2	
D	Short Left Lintel	2	
E	Short Right Lintel	2	
F	Post	4	
G	Long Top Bar Tube	4	
H	Long Support Connecting Tube	4	
I	Short Top Bar Tube	2	
J	Short Top Bar Tube	2	
K	Small Top Bar Tube	4	
L	Small Center Connector	1	
M	Long Screen Rod	4	


ITEM	DESCRIPTION	QTY.	ILLUSTRATION
N	Short Screen Rod	4	
O	U-Shaped Connector	4	
P	Middle Beam Down Connector	4	
Q	Small Canopy	1	
R	Big Canopy	1	
S	Screens	4	
T	Bolt \Flat Washer\ Nut M6*15mm	20	
U	Bolt \Flat Washer M6*15mm	8	
V	Bolt \Flat Washer M6*30mm	8	
V1	Bolt \Flat Washer M6*28mm	24	
W	Allen Wrench	1	
W1	Wrench	1	
X	Stake	12	
Y	Hanging Loops	44	
Z	Hook Decoration Accessory	1	
Z1		1	

1




Fix U-Shaped Part (O) on post (F) with screw;

2




Fix Left Lintels (B/D) with Right Lintels (C/E) with Screw (U) , Fix U-Shaped Connector (P) and Screen Rod (M/N) on lintels with Screw (V1) ;

3




Fix lintels (B/E) with Post (F) use screw (T) ;

4




Insert Long Support Connecting Tube (H) into Long Bar Tube (G) ;

5




Insert Long Top Bar Tube (G) and Short Top Bar Tube (I/J) into Center Connector (A) ,Fix Short Bart Tube (I) on Middle Beam Down Connector (P) with screw (V) , Fix Long Support Connecting Tube (H) with U-Shaped Connector (O) with Screw (V) ;

6



Insert each small top bar (K) into the small center connector (L). Attach the small roof (Q) on the small top bar (K), then secure with the decoration ball (A);


7



Place the fabric cover (R) loosely on top of the assembly. Insert each small top beam (K) into the long top connector pole (G).


Note: Put each small top beam (K) loosely on each long top connector pole (G) first, then insert together, otherwise the last one won't insert correctly.

8



Tighten the fabric cover (R) by pulling over the four small connector poles as shown.

9



Hanging Screen (S) on Screen Rod (M/N) with Hanging Loops (Y) , Fix the Stake (X) with Post (F) firmly .