


TV STAND-N710P455205P

Assembly Instructions-Please keep for future reference.



DIMENSIONS

width-68.9inch
Depth-15.75inch
height-19.29inch



















Important-Please read these instructions fully before starting assembly.

components - fittings

Please check you have all the panels listed below.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

Hardware-Liste : TV STAND-N710P455205P



 X 1	 X 1	 X 1
 X 1	 X 1	 X 1
 X 1	 X 1	 X 2
 X 1	 X 1	 X 1
 X 1	 X 1	 X 2
 X 2	 X 1	 X 1

components - fittings

Please check you have all the panels listed below.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

Hardware-Liste : TV STAND-N710P455205P












<div>19</div> <div></div> <div>X 1</div>	<div>20</div> <div></div> <div>X 1</div>	<div>21</div> <div></div> <div>X 4</div>
<div>22</div> <div></div> <div>X 1</div>		

components - fittings


Please check you have all the panels listed below.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

Hardware-Liste : TV STAND-N710P455205P


<div>A</div> <div></div> <div>M6x35mm</div> <div>X 18</div>	<div>B</div> <div></div> <div>Φ15mm</div> <div>X 18</div>	<div>C</div> <div></div> <div>Φ8x30mm</div> <div>X 16</div>	
<div>D</div> <div></div> <div>M4x40mm</div> <div>X 20</div>	<div>E</div> <div></div> <div>M3.5x14mm</div> <div>X 85</div>	<div>F</div> <div></div> <div>X 12</div>	
<div>G</div> <div></div> <div>X 2</div>	<div>H</div> <div></div> <div>X 4</div>	<div>I</div> <div></div> <div>X 1</div>	
<div>J</div> <div></div> <div>Ø20mm</div> <div>X 16</div>	<div>K</div> <div></div> <div>M4x12mm</div> <div>X 2</div>	<div>L</div> <div></div> <div>X 2</div>	<div>M</div> <div></div> <div>X 2</div>
<div>N</div> <div></div> <div>X1</div>	<div>O</div> <div></div> <div>X 4</div>	<div>P</div> <div></div> <div>X 2</div>	<div>Q</div> <div></div> <div>M4x20mm</div> <div>X 4</div>
<div>R</div> <div></div> <div>X 4</div>	<div>CL</div> <div></div> <div>350mm</div> <div>X 2</div>	<div>DL</div> <div></div> <div>350mm</div> <div>X 2</div>	
	<div>CR</div> <div></div> <div>350mm</div> <div>X 2</div>	<div>DR</div> <div></div> <div>350mm</div> <div>X 2</div>	

Assembly Instructions




Assembly Instructions

STEP 1





STEP 2



Assembly Instructions


STEP 3





E	x12	CL	x2	CR	x2
					
M3.5x14mm		350mm		350mm	


STEP 4




B	x4	C	x4	J	x4
					
Ø15mm		Φ8x30mm			

Assembly Instructions


STEP 5




B	x4	C	x4	J	x4
					
Ø15mm		Φ8x30mm			

Assembly Instructions

STEP 6





STEP 7



Assembly Instructions


STEP 8



C	x8	D	x8
			
Φ8x30mm		M4x40mm	


Assembly Instructions

STEP 9



E	x23	H	x4	I	x1
					
M3.5x14mm					


STEP 10



R	x4
	



Assembly Instructions

STEP 11



N	x1
	


STEP 12




E	x12	F	x12
			
M3.5x14mm			


Assembly Instructions


STEP 13





E	x8	O	x4	P	x2	Q	x4
							
M3.5x14mm						M4x20mm	

STEP 14




E	x16
	
M3.5x14mm	

STEP 15




To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.

Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.


Turning the screw "C" on BOTH hinges on each door.

Assembly Instructions

STEP 16




STEP 17




Assembly Instructions




STEP 18




STEP 19




STEP 20



STEP 21



D	x2	K	x2	L	x2	M	x2
							
M4x40mm		M4x12mm					